



MODEL NMG-118-T4

OPERATION, SERVICE AND PARTS MANUAL



Address: 4075 East Market Street York, PA 17402-5100 USA

Telephone: 717-840-4500 Telefax: 717-840-4501

www.klingecorp.com

MANUFACTURED BY KLINGE CORPORATION

REVISION RECORD

[illegible]

Table of Contents

Service Request	4
Spare Parts Request	4
Use of this Manual	4
SECTION 1 SPECIFICATIONS	5
1.1 GENERAL	5
1.2 CONSTRUCTION	5
1.3 ENGINE	5
1.4 ALTERNATOR	5
1.5 TEMPERATURE OPERATING RANGE	5
1.6 WEIGHT	5
1.7 MOUNTING	5
1.8 FUEL SUPPLY	5
1.9 POWER SUPPLY	6
1.10 CONTROLS	6
1.11 ELECTRICAL STARTING SYSTEM	6
1.12 FUEL SYSTEM	6
1.13 LUBRICATION SYSTEM	6
1.14 COOLING SYSTEM	7
1.15 COMBUSTION AIR CLEANING SYSTEM	7
SECTION 2 SAFETY PRECAUTIONS	8
2.1 ROTATING HAZARDS	8
2.2 BATTERY HAZARDS	8
2.3 NOISE HAZARD	8
2.4 ELECTRICAL HAZARDS	8
2.5 GENERAL SAFETY PRECAUTIONS	9
2.6 SAFETY DO'S AND DON'TS	10
SECTION 3 GENERATOR SET OPERATION	11
3.1 PRE-START INSPECTION	11
3.2 STARTING THE UNIT	11
3.3 AFTER START CHECK-UP	11
3.4 SHUTTING OFF THE ENGINE	11
3.5 LED INDICATORS	12
3.6 ENGINE SPEED (RPM)	12
SECTION 4 MAINTENANCE AND COMPONENT INFORMATION	14
4.1 FUEL SYSTEM	14
4.2 COMBUSTION AIR INTAKE SYSTEM	14
4.3 LUBRICATION	14
4.4 COOLING SYSTEM	14
4.5 FAN BELT	15
4.6 BATTERY	15
4.7 STARTER AND BATTERY CHARGING ALTERNATOR	15
4.8 SERVICING SCHEDULE	16
4.9 PTI FORM	16
SECTION 5 TROUBLESHOOTING	17
5.1 TROUBLE SHOOTING	17
SECTION 6 SERVICE PARTS	21

Service Request

Requests for Service should be directed to the Klinge Service Team. The below link should be used to place all requests for service and will afford the quickest response time.

<https://klingecorp.com/request-service/>

This form will help us determine model and age of the equipment, location, basic details about the issue, who to contact and how to best handle the issues with the equipment. A service ticket number will be provided in a response email once the form is received and processed. If the equipment is out of warranty, charges may apply for extensive technical support.

Additionally, our Service Department can be reached via email at technical@klingecorp.com.

Spare Parts Request

Requests for Spare Parts should be directed to our Parts Department via email at spares@klingecorp.com. Please have available at the time of the request the Serial Number of the equipment to ensure that the proper part is provided.

Use of this Manual

The use of this manual is intended for the safe operation of the equipment described. It is therefore reasoned that persons who have the occasion to use this manual have a knowledge of mechanical and electrical systems and components addressed by its' contents. However, efforts have been made to enable persons less familiar with these systems to use this manual.

The equipment may be installed in a number of configurations. Each may have optional items and differing external details provided by third parties. The specific electrical diagram is posted on the unit as decals.

Suggestions as to improvement in content and format are welcome and should be addressed to engineering@klingecorp.com. Corrections and improvements will be included on dated revisions – the latest of which will be available upon request.

SECTION 1 SPECIFICATIONS

1.1 GENERAL

The NMG-118-T4 (Nose Mount Generator Set) was specifically designed to meet the rigorous demands of ocean, over-the-road, and rail transport of 20' and 40' refrigerated containers. The NMG-118 can be mounted quickly in the nose of a container, using only four bolts.

The genset meets the EPA T4 regulations as confirmed via extensive testing by the engine manufacturer, Isuzu.

1.2 CONSTRUCTION

Welded aluminum frame
Aluminum doors and closures
Stainless steel hardware

1.3 ENGINE

ISUZU 4LE2 Tier 4/Stage 3B
Liquid cooled diesel, four cylinder; 2.2L; 4 stroke; OHV; direct injected; turbocharged; glow plug assisted Start.
30 kW (40.2 BHP) @ 1800 RPM rated output

1.4 ALTERNATOR

28.4 kW / 35.5 kVA RFL, specifically designed for starting 3 phase AC electrical motors.
Single bearing, 10 lead, 1800 RPM, Y 480 volts, 0.8 power factor lagging.
NOTE: The output voltage is not adjustable but is directly related to the engine's speed.
Normal readings at 1800 RPM (60 Hz) are between 460 and 500 V.

1.5 TEMPERATURE OPERATING RANGE

From -30°C to +50°C (-20°F to +125°F)

1.6 WEIGHT

- 500 kg (1100 lbs.) without fuel
- 685 kg (1510 lbs.) with full fuel tank

1.7 MOUNTING

Mounting clip in back, 4 bolts in front

1.8 FUEL SUPPLY

The generator set has an incorporated fuel tank with a capacity of 170 L (45 US gallons) that can provide approximately 22 hours of operation under full load.

1.9 POWER SUPPLY

STANDARD: 28 kVA - 460 V AC / 3 phase / 60 Hz
40 A power circuit breaker
CEE 17 - 32 A power receptacle

1.10 CONTROLS

- Two toggle switches
 - Start switch: OFF-ON-START
 - Engine speed switch: 1000 RPM-1800 RPM
- Isuzu Power View monitors:
 - ENG RPM
 - OIL PRESS
 - COOL TEMP
 - BAT VOLT
 - ENG TORQ
 - MACH HRS
 - FUEL TEMP
 - FUEL RATE
 - INT MFLD T
 - BOOST PRESS
 - SYS VOLT
 - BOST PRES2

1.11 ELECTRICAL STARTING SYSTEM

- Battery: 12V, Group 31 – 950 CCA @ 0°F
- Battery Charging Alternator: 20 or 35 A, 14 VDC
- Starter Motor: 2.0 kW, 12V Gear Reduction type
- Glow plug assisted start with control resistor

1.12 FUEL SYSTEM

- Pre-Fuel Filter w/Water Sedimenter, paper element type w/drain, remote mount
- Pre-Pump, electrical 12 V fuel supply pump, remote mount
- Main Fuel Filter w/Water Sedimenter paper element type with priming pump, w/drain, remote mount
- Engine integrated fuel pump
- Direct injection cylinders

1.13 LUBRICATION SYSTEM

- Full pressure system with trochoid type Oil Pump, driven from the crankshaft.
- Oil pan made out pressed stamped steel, full sump, with a capacity of 8.4 liter (8.9 U.S. quarts).
- Full flow, spin-on Oil Filter, replaceable paper element type.

1.14 COOLING SYSTEM

- Pressurized liquid (50/50 water / glycol mixture) forced circulation by Centrifugal Pump.
- Thermostat, wax pellet type, opening at 76.5°C (170°F).
- Cooling fan suction type, plastic 6 blades, 400mm (15.75") diameter
- Heavy duty 4 row, 3 pass copper / brass Radiator.
- High coolant temperature switch, normal open, single pole, closing at 105°C (221°F).

1.15 COMBUSTION AIR CLEANING SYSTEM

- One high performance single stage Cyclopac® air filter with extended life dry cartridge and automatic dust and water expelling Vacuator™ Valve.
- Air cleaner restriction indicator for maximum filter life.

SECTION 2 SAFETY PRECAUTIONS

Safety Glasses should be worn at all times when operating or servicing the Generator Set.

2.1 ROTATING HAZARDS

1. Keep your hands, clothing, and tools clear of the alternator belt when the generator set is running.
2. If it is necessary to run the generator with a removed cover, be very careful with tools or meters being used in that area to avoid contacting the rotor.

2.2 BATTERY HAZARDS

Few people realize just how dangerous a battery can be.

The electrolyte in a lead acid battery is dilute sulfuric acid (H_2SO_4). During charge or discharge functions of a battery, a chemical change takes place within the individual cells that cause the bubbling we see through the filler hole. This gas bubbling is hydrogen and oxygen, and it is **EXPLOSIVE**. If during this gassing action, a means of ignition is present, an explosion could occur. A defective battery may suddenly explode even while standing idle. Added to this danger, consider a fall-out of highly corrosive sulfuric acid caused by the explosion.

PRECAUTIONS

1. Always wear eye protection when servicing batteries. If electrolyte is splashed on the skin or in the eyes, flush immediately under running water. Obtain medical help as soon as possible.
2. When charging batteries, do not remove the vent caps.
3. When disconnecting or reconnecting the generator set battery make sure the ON/OFF switch is in the **OFF** position to prevent an arc, which could cause the battery to explode. Disconnect the ground cable first, preferably at a point away from the battery. Reconnect the ground cable last, again away from the battery if possible.
4. **DO NOT** check a battery by "sparking" across the posts. Eye injury from the arc or explosion may occur.

2.3 NOISE HAZARD

When servicing or operating the Generator Set in a running condition, personal protective hearing equipment should be worn when exposure is longer than 8 hours.

2.4 ELECTRICAL HAZARDS

HIGH VOLTAGE

When servicing or repairing a generator set, the possibility of serious or even fatal injury from electrical shock exists. Extreme care must be used when working with an operating generator. Lethal voltage potentials can exist on connections that are in the exciter control box.

Special attention should be given to the Main Power Plug and Receptacle when disconnecting from each other. When disconnecting these two items ensure that the power circuit breaker has been turned to the off position. Do not pull at the cable but rather with a firm grip on the housing,

grab the plug and receptacle and pull apart. If the cable is used rather than the housing the risk exists that the wires within the housing could become dislodged and lead to a future electrical hazard.

PRECAUTIONS

1. When working on high voltage circuits on the generator sets, **DO NOT** make any rapid moves. If a tool drops, **DO NOT** grab for it. People do not contact high voltage wires on purpose. It occurs from an unplanned movement.
2. Make sure of your footing. If you slip, you will instinctively grab for support. This can be lethal around a generator set. Work on rubber mats or dry wood if possible.
3. Use tools with insulated handles that are in good condition. Never hold metal tools in your hand if exposed energized conductors are within reach.
4. Treat all wires and connections as high voltage until a meter and wiring diagram show otherwise.

IMMEDIATE ACTION must be initiated after a person has received an electrical shock. Obtain expert medical assistance if available.

Immediately remove the source of shock by either shutting it down or removing the victim from the source. If it is not possible to shut off the generator set, the wire should be cut with an insulated tool (e.g. a wooden handled axe or cable cutters with heavy insulated handles), or a rescuer wearing insulated gloves. Whichever method is used, **DO NOT** look at the wire while it is being cut. The ensuing flash can cause blindness. Remember that insulated gloves **MUST BE** insulated and not just rubber gloves manufactured for protection from liquids. If the victim has to be removed from live circuitry, pull him off with a non-conductible material. Use his coat, a rope, a piece of dry wood or loop your belt around his leg or arm and pull him off. **DO NOT TOUCH THE PERSON**, you could receive a shock from current flowing through his body. After separating the victim from the power source, check immediately for respiration and presence of pulse. If a pulse is present, respiration might be restored by mouth-to-mouth resuscitation.

LOW VOLTAGE

Control circuits utilized by the generator set are low voltage (12 VDC). This voltage potential is not considered dangerous, but the large amount of current available (over 300 amps) can cause severe burns if shorted to ground.

1. Disconnect the negative terminal of the battery if possible when working on the generator set. Disconnect the cable end that is away from the battery.
2. **DO NOT** wear jewelry, watches, or rings. These items can short out and cause severe burns to the wearer.

2.5 GENERAL SAFETY PRECAUTIONS

1. To prevent against a possible personnel burn injury the following precautions should be followed:
 - a. Do not touch the muffler, exhaust pipe or exhaust manifold while the unit is in operation or immediately after stopping the unit. The unit should be allowed to cool to an acceptable level prior to performing service in these areas.
 - b. Do not touch the radiator cap or attempt to add coolant to the engine while the unit

is in operation or immediately after stopping the unit. The unit should be allowed to cool to an acceptable level prior to opening the radiator cap.

2. Use extreme caution if holes are drilled into the generator set. Holes drilled into an electrical wire can cause fire, explosion, or shock hazard.
3. Ensure all mounting screws are tight and are the correct length.
4. Keep tools and equipment clean and in good working condition. Accidents occur when you attempt procedures without the proper tools.

2.6 SAFETY DO'S AND DON'TS

DON'T -

DON'T allow inexperienced personnel to work on the generator or electrical equipment.

DON'T remove guards or protective devices.

DON'T wear loose clothing or jewelry in the vicinity of moving parts. These can get in machinery, with disastrous results.

DON'T wear jewelry while working on electrical equipment. If your hair is long, wear a head covering. Hair caught in a drill press, fan belt or other moving part can cause serious injury.

DON'T stand on a wet floor while working on electrical equipment. Use rubber insulated mats placed on dry wood platforms.

DON'T lunge after a dropped tool. To do so may place you in a position of extreme danger.

DON'T commence any operation until you have taken all the necessary steps to ensure that you are in complete safety.

DO -

DO perform your tasks carefully, without undue haste.

DO provide fire extinguishers (rated ABC).

DO provide a First Aid Kit (for burns and abrasions). Obtain medical attention, if necessary.

DO use the correct tools for the job you are doing.

DO make sure that all fasteners are secure.

DO use extreme care while making adjustments on the generator set while it is running.

DO keep your hands away from moving parts.

DO remember - Horseplay is for horses! It has no place around machinery.

DO disconnect batteries before starting work on the generator set.

DO use screwdrivers, pliers, diagonal pliers, etc. with insulated handles.

DO remember to keep one hand in your pocket if it is necessary to work on "**live**" circuits. To do so will prevent passage of electricity into one hand and out the other, which passes current across the heart.

DO PRACTICE SAFETY. THE LIFE YOU SAVE MIGHT BE YOUR OWN

SECTION 3 GENERATOR SET OPERATION

3.1 PRE-START INSPECTION

1. Check fuel level - Use Diesel fuel SAE No. 2-D, No. 1-D in cold weather, or any other equivalent low sulphur content diesel fuel as DIN EN 590; BS 2869 Class A-1; JIS No.2; NATO Code F-54 / F-34 / F-44 and XF-63.
2. Check engine oil level – should be at full mark
Use SAE multi-grade oil 10W-40 API rating CC/CD or higher for normal operation and SAE 5W-20 when operating at temperatures below -4°F (-20°C).
3. Check coolant level – should be between the two marks on the overflow bottle.
4. Check fan belt for tension and integrity.
5. Make sure that the generator's main circuit breaker located in the window of the genset left-hand door is in "OFF" position (right).
6. Ensure the refrigeration unit plug is connected to the generator set power receptacle.

3.2 STARTING THE UNIT

1. Ensure the Engine Speed Switch is set to 1000 RPM.
2. Move the OFF-ON START switch to ON, when the PREHEAT LED goes out (will not illuminate in warmer ambient conditions) toggle the switch to START. Release the switch when the engine has started.
3. Allow the engine to run for a minimum of 10 seconds to become stable at 1000 RPM.
4. Change engine speed switch to 1800 RPM.

3.3 AFTER START CHECK-UP

Look for the following in the Power View window:

- ENG RPM = 1800 \pm 5
- BAT VOLT = 12.8 VDC or greater
- OIL PRESS = 2 BAR or higher

When the above conditions are met it is safe to switch the main circuit breaker to ON.

There are several safety devices employed to prevent damage to the engine, or the electrical system, should a potentially dangerous situation occur.

The 25 A circuit breaker protects DC components and wiring from a short circuit situation. The circuit breaker will reset periodically until the short circuit is removed.

WHEN A DC CIRCUIT BREAKER IS REPLACED IT MUST BE INSTALLED PROPERLY WITH THE "BAT" TERMINAL CONNECTED TO THE LINE OR BATTERY SIDE OF THE CIRCUIT AND THE "AUX" TERMINAL CONNECTED TO THE LOAD SIDE OF THE CIRCUIT AS INDICATED ON THE CIRCUIT BREAKER.

Two safety shutdown devices are used to protect the engine. One is the high temperature switch that actuates at 221°F (105°C). The other is an oil pressure switch that actuates at 14 psi (1kg/cm²).

3.4 SHUTTING OFF THE ENGINE

Switch the engine speed to 1000 RPM and allow to run for 3 minutes before switching the start switch to OFF. This will give time for the turbo to cool, extending the life of the turbo/engine.

3.5 LED INDICATORS

The electrical control system is provided with a high intensity red LED located on the upper front of the control box.


This red LED indicates when it is safe to start the engine, based on the temperature following the system's use of glow plugs in low ambient temperature conditions.

3.6 ENGINE SPEED (RPM)

The engine must be set to run at 1000 RPM at start-up.

After allowing the engine to run for 10 seconds to warm up the turbo, the engine speed switch is to be set to 1800 RPM before a load is put on genset.

UNCONTROLLED WHEN PRINTED



SECTION 4 MAINTENANCE AND COMPONENT INFORMATION

4.1 FUEL SYSTEM

The fuel injection pumps and fuel injection nozzles are precisely manufactured and therefore using fuel which contains water or dust particles will result in equipment seizure, costly damages and decreased engine output.

Replace fuel filter element after every 500 hrs of operation.

Use KLINGE K26-25310-08 pre-filter element and K26-25310-09 main filter element.

Before starting the unit check for leaks and for water in the filter bowl. Drain if necessary.

Use SAE No.2-D Diesel fuel, 1-D in cold weather.

The following standards are also approved: DIN EN 590; BS 2869 Class A-1; JIS No.2; NATO Code F-54 / F-34 / F-44 and XF-63.

DO NOT USE:

- Diesel fuel that has been contaminated with engine oil, this can cause engine damage and can also affect emission control.
- Fuel additives, except “Biocide” type, if required.

4.2 COMBUSTION AIR INTAKE SYSTEM

Engine performance and life depends on the intake air condition.

Replace air filter cartridge after every 500 hours of operation.

Use KLINGE K26 25091 08 filter cartridge.

After 100 hours of operation, or more often if the generator set is operated in a dusty environment, remove the filter cartridge and blow air at a pressure of 3 – 6 BAR (45 –70 PSI) only from the inside, to remove the dust.

Take care to not damage the filter element during the cleaning and to not cause air leakage (sucking) when the air cleaner is reassembled.

4.3 LUBRICATION

A correct oil and filter service will ensure good performance and a long engine life.

Change oil and filter after initial 50 hours of operation.

Afterwards change the oil every 250 hours and filter every 500 hours of operation or at least once in a year.

Use SAE multi-grade oil SAE 10W-40 API rating Cj-4 or higher and SAE 5W-20 when operating at temperatures below -20°C (-4°F).

Use KLINGE XB-998209 filter element.

Check the oil level before every start, add oil if required, up to the FULL mark.

CAUTION: Never mix up different brand or different type of oils.

4.4 COOLING SYSTEM

Use 50/50 Ethylene Glycol / Water solution. Never exceed 60 / 40 antifreeze water mix.

NOTE: Concentrations over 65% Ethylene Glycol adversely affect freeze protection, heat transfer rates and silicate stability that may cause water pump leakage.

Replace coolant every two years.

Check the hoses and pump for leaks and the coolant level, before every trip of the unit. With a cool engine the liquid level should be between the two marks on the expansion tank.

4.5 FAN BELT

Check the fan belt for tension and integrity before every start.

Replace if necessary, using KLINGE K26 25310-20 belt.

4.6 BATTERY

Keep the battery fully charged all the time, it is important especially in cold seasons.

Keep the battery posts clean and the battery cables tightened securely.

Always disconnect the battery negative cable when work on the unit is performed.

If distilled water is needed to be added, do it before the unit will be operated, otherwise the water will not mix with the acid and can freeze in cold weather.

4.7 STARTER AND BATTERY CHARGING ALTERNATOR

The starter and the battery charging alternator servicing consists of:

- Check the carbon brushes and the brush contact.
- Clean the alternator slip ring.

Avoid spraying water or steam on the alternator and on the starter, it may cause damage.

4.8 SERVICING SCHEDULE

	Daily or Weekly	Initial 50 Hours	Every 250 Hours	Every 500 Hours	Every 1000 Hours	Every 2000 Hours
GENERATOR SET (NMG-118)						
Check Fuel Level / add if needed	X					
Check sediment bowl on fuel filter (Drain water and clean if needed)		X	X			
Replace Fuel Filter				X		
Replace Air Filter Insert (More frequent may be required based on operating area)				X		
Check Oil Level / add if needed	X					
Replace Oil Filter		X		X (Min Yearly)		
Replace Oil		X	X (Min Yearly)			
Check for fluid leaks	X	X				
Check radiator coolant level/ add if needed	X					
Inspect and if needed clean radiator fins			X			
Flush radiator and replace coolant and hoses						X
Inspect and adjust cooling fan V-belt		X	X			
Replace V-belt						X
Inspect and clean Vacuator valve (Air Filter)			X			
Check engine for unusual noises or exhaust smoke	X		X			
Ensure battery terminals are tight			X			
Check main circuit breaker plastic boot			X			
Inspect unit and generator set for damaged, loose, or broken parts, missing bolts			X			
Check condition of mounting bolts		X	X			
Check condition of engine and alternator mounts (replace if necessary)		X			X	

- In addition to the above checklist the normal Pre-Trip Inspection Form should also be completed every 2 months.

4.9 PTI FORM

It is important that a Pre-Trip Inspection (PTI) be completed prior to each shipment.

The NMG-118-T4 PTI form can be found on Klinge's website at:

<http://www.klingecorp.com/pti/>

SECTION 5 TROUBLESHOOTING

5.1 TROUBLE SHOOTING

The following trouble shooting chart is by no means complete, but covers the more general type problems, which would most likely occur if a breakdown is experienced.

POSSIBLE CAUSE	CORRECTIVE ACTION SUGGESTED
<hr/> Problem: Engine starter will not energize	
Loose or corroded battery terminals	Clean terminals and tighten
Battery voltage too low	Recharge or replace battery
Faulty START / PREHEAT switch	Replace
Faulty ON / OFF switch	Replace
Faulty starter solenoid	Replace
Faulty starter motor	Replace
Circuit breaker open	Replace if it does not reset
<hr/> Problem: Starter turns but engine does not ignite	
Faulty control relay R1	Replace
Faulty emergency stop timer	Replace
Faulty engine fuel solenoid	Replace
Control rack is stuck in stop position	Remedy
Engine too hot and protection system will not allow to operate	Allow engine to cool
Faulty coolant temperature switch	Replace switch
Faulty electrical fuel pump	Replace
No fuel	Add fuel to tank
Clogged fuel filter element	Replace
<hr/>	

POSSIBLE CAUSE	CORRECTIVE ACTION SUGGESTED
Problem: Engine starts but stalls immediately	
Air in the fuel system	Remedy and bleed the system
Defective oil pressure switch Low oil pressure LED stays ON	Replace switch
Oil level to low	Add oil
Problem: Engine stops with high engine temperature indication	
Coolant temperature too high	Check cooler for air flow restriction and clean or remove restriction
Coolant level too low	Add coolant
Defective high temperature switch	Replace switch
Thermostat malfunction	Replace
Fan belt slippage or broken	Remedy or replace
Problem: Black exhaust	
Clogged air filter	Clean the filter cartridge or replace
Improper fuel – low cetane grade	Replace fuel
Nozzle damage	Repair or replace nozzle
Problem: White smoke	
Water mixed in fuel	Replace fuel and clean fuel filter
Low compression pressure	Check compression
Low coolant temperature	Check thermostat and replace if needed
Problem: Unstable engine running (Hunting)	
Defective governor spring	Replace
Incorrect valve adjustment	Adjust valve clearance

POSSIBLE CAUSE**CORRECTIVE ACTION SUGGESTED****Problem: No voltage at power receptacle but AC voltmeter needle is in the green band**

Main circuit breaker is on OFF position

Turn main circuit breaker ON

Defective main circuit breaker

Replace

Problem: No AC voltage

No residual magnetism in the alternator exciter field

Restore magnetism by flashing field

Open in main stator windings

Check for continuity in windings

* Open or short in rotating diodes

Check rotating diodes and replace if needed

* Open in alternator field

Check for continuity. If field coils are open, replace the rotor or repair it.

* Shorted exciter armature

Check for short and replace if faulty. Use a Kelvin type bridge to measure this resistance

* Shorted leads between exciter armature and generator field

Test and repair

NOTE: * Designated rotating parts. The rear alternator cover (bearing carrier) must be removed in order to perform the test.

For instructions how to perform the tests see "ALTERNATOR MANUAL" at the end of this Manual.

Problem: Low voltage

Low speed

Check engine speed or system for overload.

Excess load

Reduce load. The load on each leg should be as evenly balanced as possible and should not exceed the rated current on any leg.

High resistance connections –
Connections will be warm or hot

Make better connections, electrically and mechanically.

Shorted field

Test field coils for possible short. Use an Ohmmeter or resistance bridge. Repair or replace rotor if alternator field coils are shorted.

POSSIBLE CAUSE**CORRECTIVE ACTION SUGGESTED****Problem: Fluctuating voltage**

Irregular engine speed

Check engine for malfunction.

Loose terminal or load connections

Make better connections.

Defective bearing causing uneven gap

Replace alternator bearing.

Problem: Overheating

Generator overloaded

Reduce load. Check with ammeter and compare with alternator nameplate rating.

Unbalanced load

The load on each leg should be as evenly balanced as possible and should not exceed the rated current on each leg.

Dry bearing

Replace bearing


Clogged vent ducts

Clean air passages


SECTION 6 SERVICE PARTS


LIST OF CONTENTS


Unit Genset NMG-Tier 4 Isuzu Engine/RFL Alternator 18 kW	22
Engine / Alternator Assembly Tier 4	31
Box Control	38
Alternator RFL-30 Modified w/Breaker Box	40


1	2	3	4	5	6	7	8	9	10	11	12
DRAWING NO. 460-18902-00	DO NOT SCALE										CHANGE NO (DRAWN) APPROVED
											
ITEM NO	PART NO	DESCRIPTION	QTY	ITEM NO	DESCRIPTION	QTY	ITEM NO	DESCRIPTION	QTY	ITEM NO	DESCRIPTION
118	K21-16548-09	CLAMP CS VINYL COATED 0.812" ID 3/4" WIDE	2	79	K21-16593-10	NUT LOCK SS M10 X 1.5 NYLON INSERT	39	38	060-18893-00	HOSE RADIATOR INLET DAYCO	1
117	K21-15797-04	WASHER LOCK EXT INT SS #10	1	78	K21-15026-30	SCREW, HEX, SS, FULL THREAD, M10 X 1.5 X 30	18	38	060-18894-00	HOSE RADIATOR OUTLET NMG TIER 4	1
116	K21-16523-03	SCREW HEX SS M5 X 0.80 X 10 LONG 18-8 FULL THREAD	1	77	K21-16547-12	WASHER, FLAT, STAINLESS STEEL, M12 X 37 X 3	8	37	060-14473-00	HOLDER RADIATOR OUTLET HOSE NMG-115-10	1
115	K21-16548-29	CLAMP CS VINYL COATED 1.75" ID 1.00" WIDE	1	76	K21-16583-12	NUT LOCK SS M12 X 1.75 NYLON INSERT	4	36	360-14506-02	CABLE BATTERY NEGATIVE BLACK BOOT 41 INCH LG	1
114	K21-18505-06	WASHER, FLAT, STAINLESS STEEL, M6 X 14.3 X 1.27	1	75	K21-150271-80	SCREW HEX SS M12 X 1.75 X 80 18-8 PARTIAL THREAD	4	35	360-14506-01	CABLE BATTERY POSITIVE RED BOOT 41 INCH LG	1
113	K21-150226-20	SCREW HEX SS M10 X 1.5 X 20 LONG 18-8 FULL THREAD	2	74	K21-150401-10	WASHER, FLAT, STAINLESS STEEL, M10 X 20 X 2	18	34	XB-993011-02	RUBBER PAD - BATTERY 3.0W X 12.0M LG	2
112	K21-150421-03	WASHER LOCK SPG SS M5 X 9.2 X 1.2 THK	1	73	K21-150226-25	SCREW, HEX, SS, FULL THREAD, M10 X 1.5 X 25	2	33	XB-993011-22	RUBBER NEOPRENE 3/16" X 2.0" X 8.5"	1
111	K26-25310-03	FUEL LOW PRESSURE PUMP (SUZUKI NMG TIER-4)	1	72	K21-14072-00	WASHER FLAT STAINLESS STEEL 5/16 X 0.88 X 18-8	2	32	K25-25912-00	BATTERY, 12 VOLT, TOP STUDS WITH NUTS	1
110	K26-24666-00	INDICATOR AIR RESTRICTION 20" H2O	1	71	060-14493-00	BRACKET SS BATTERY HOLD-DOWN	1	31	360-18911-01	BRACKET FUEL MAIN FILTER PAINTED	1
109	K21-15649-08	CLAMP CUSH SS 3/4 ID 28 MOUNTING HOLE	2	70	K21-14921-07	NUT, LOCK, STAINLESS STEEL 5/16 - 18	2	30	360-18911-01	BRACKET FUEL MAIN FILTER PAINTED	1
108	K21-15649-08	CLAMP CUSH SS 3/4 ID 28 MOUNTING HOLE	2	69	XB-209049	ROD BATTERY HOLD DOWN NMG-115-10	2	29	360-18922-00	BOX CONTROL WHITE	1
107	360-18970-00	BOX BREAKER (TOP MOUNT)	1	67	K21-150401-08	WASHER, FLAT, STAINLESS STEEL, M8 X 17 X 1.4-1.8	4	27	XB-993000-18	RUBBER NEOPRENE 1/8" X 1.0" X 4.0"	2
106	K23-13427-14	FITTING 90 DEG 3/8 HOSE 14mm BANJO	1	66	K21-150225-25	SCREW HEX SS M8 X 1.25 X 25 LONG 18-8 FULL THREAD	15	26	XB-205126	BRACKET ASSEMBLY RADIATOR HOLD-DOWN	1
105	K21-16686-10	CLAMP OETIKER SS DOUBLE PINCH (15-18MM)	8	65	K21-16245-10	WASHER FLAT SS #8	1	25	XB-993011-03	RUBBER 3/16 X 3.0 X 9.0	2
104	K23-07981-00	CLAMP HOSE SS 1.81 TO 2.75 DIA. RANGE	4	64	K21-14921-02	NUT LOCK SS NO 8-32 18-8	1	24	XB-340075	RADIATOR 4 ROW / 3 PASS NMG ISUZU ENG	1
103	K28-10804-06	HOSE NEOPRENE PUSH LOCK BLACK (QTY IN FT)	9	63	XB-991434-10	SCR FLAT SS HB-32 X 1-1/4 PHIL 18-8	1	23	360-18855-00	SHROUD FAN ASSEMBLY TIER 4 NMG	1
102	K29-18490-00	HOOK STRAP SS 0.125 DIA. WIRE	6	62	K21-150401-06	WASHER FLAT, STAINLESS STEEL, M6 X 12 X 1.4-1.8	8	22	060-18854-01	POST RADIATOR FRONT PAINTED NMG T4	1
101	K28-10691-00	STRAP 15" LG NO HOOKS	3	61	K21-16526-30	STUD FLUSH M6 X 1.0 X 30MM LG	2	21	060-18853-01	ANGLE RADIATOR TOP SUPPORT PAINTED	1
100	K28-10797-00	GROM 875x125x1875	1	60	K21-150421-10	WASHER, LOCK, SPRING, SS, M10 X 18.4 X 2.5	18	20	360-18850-01	POST REAR RADIATOR SUPPORT NMG TIER-4	1
99	K26-25095-04	HOOD AIR INLET PLASTIC STYLE E FITS 2.50 OD FILTER	1	59	K21-18510-08	WASH INSUL PVC M8 25.4/8.4MM OD/ID 0.02 IN 0.51MM	66	19	360-11014-00	CLIP RETAINING	2
98	K28-11155-00	HOSE ADAPTER PCV VENT TUBE	1	58	K21-150225-30	SCREW HEX SS M8 X 1.25 X 30 18-8 FULL THREAD	39	18	060-18943-01	RETAINER POWER CABLE PAINTED	2
97	K28-11154-00	ELBOW 90 DEG 1.50" - 2.00" ID, SILICONE	1	57	K21-16638-25	SCR FLAT SS M8-1.25 X 25 LG	7	17	060-18849-01	ANGLE DIAGONAL SUPPORT TOP PLATE PAINTED	1
96	K28-11156-00	ELBOW 90 DEG 2.00" - 2.25" ID	1	56	K21-150421-06	WASHER, LOCK, SPRING, SS, M6 X 12.2 X 1.5	10	16	360-18847-01	POST ASSEMBLY FRAME REAR PAINTED	1
95	K26-24667-00	BAND AIR CLEANER MTG 6.5 ID	2	55	K21-150224-20	SCREW, HEX, SS, FULL THREAD, M6 X 100 X 20	14	15	060-18846-01	POST FRAME REAR PAINTED NMG TIER 4	1
94	K26-25091-00	FILTER AIR 1 STAGE 2-1/2 IN - 2-1/4 OUT	1	54	K21-18510-06	WASH INSUL PVC M6 19.6/24MM OD/ID 0.51MM THICK	31	14	360-18844-01	ANGLE TOP REAR PAINTED NMG TIER-4	1
93	360-18925-01	AIR INTAKE ASSEMBLY PAINTED NMG TIER 4	1	53	K21-16547-08	WASHER FLAT SS M8 LARGE OD 24MM 18-8 2MM THICK	72	13	360-18842-01	ANGLE TOP FRONT PAINTED NMG TIER-4	1
92	K21-16684-00	CLAMP DUAL LINE 5/8" TO 3/4" OD	1	52	K21-16547-08	WASHER FLAT SS M8 LARGE OD 24MM 18-8 2MM THICK	72	12	360-18840-01	PANEL CONTROL ASSEM PAINTED NMG TIER 4	1
91	K21-150226-40	SCREW, HEX, SS, FULL THREAD, M10 X 1.5 X 40	2	51	K21-16583-08	NUT LOCK SS M8 X 1.25 NYLON INSERT	22	11	360-18838-00	PANEL ALTERNATOR END WELDED & PAINTED WHITE	1
90	K28-11147-00	FITTING 90-DEG BARB 3/8 HOSE 9/16-18 FEMALE	2	50	K21-16231-00	CLAMP HOSE SS 0.75 - 1.50 INCH	2	10	K29-17880-01	HINGE SLIP SS 9/32 HOLES SOCK LT HAND	2
89	K21-15649-15	CLAMP CUSH SS 32mm=1.25 ID	1	49	K21-150224-10	SCREW, HEX, SS, FULL THREAD, M6 X 100 X 18	8	9	360-18890-00	PANEL TOP ASSEMBLY	1
88	K21-15649-03	CLAMP CUSHIONED STAINLESS STEEL 1/2 INCH	2	48	K21-16583-06	NUT LOCK SS M6 X 1 NYLON INSERT	17	8	360-18908-00	DOOR ASSEMBLY RIGHT NMG TIER 4	1
87	K21-10189-00	WASHER FLAT STAINLESS STEEL 1/4 X 0.28 X 0.63	6	47	K21-16547-06	WASHER, FLAT, STAINLESS STEEL, M6 X 18 X 1.6	29	7	360-18888-00	DOOR LEFT END ASSEMBLY NMG TIER-4	1
86	K21-14642-00	SCREW HEX SS 1/4-20 X 1/2 LG	6	46	K29-17879-01	HINGE SLIP SS 9/32 HOLES SOCKET	2	6	360-18885-00	PANEL ASSEMBLY REAR NMG TIER-4	1
85	K21-150103-06	NUT HEX SS M6 X 1	5	45	XB-995029	SLEEVE FIBERGLASS 1.50 1000 F	32	5	XB-999076	ISOLATOR ENGINE NEOPRENE 260 LB AXIAL 130 LB LOAD	4
84	K21-150224-25	SCREW, HEX, SS, FULL THREAD, M6 X 100 X 25	2	44	K21-12930-00	CLAMP HOSE SS 106" TO 2"	2	4	360-18814-02	CRADLE RFL ALTERNATOR BLACK	1
83	K21-16528-30	BOLT CARR SS M8 X 1.25 X 30	1	43	360-18895-10	EXHAUST ASSEMBLY PAINTED NMG TIER 4	1	3	360-18892-00	ENGINE ALTERNATOR ASSEMBLY TIER 4	1
82	060-09113-00	INSULATOR HINGE	4	42	K23-10280-00	CLAMP HOSE 138 - 63 5/16 WIDE SS	2	2	360-18874-00	TANK ASSEMBLY FUEL NMG-TIER 4	1
81	K21-18510-10	WASH INSUL PVC M10 31.8/10.3MM OD/ID 0.02 IN 0.51MM	8	41	K21-18426-02	CLAMP HOSE SS 125 TO 2125 DIA RANGE	5	1	360-18836-01	FRAME ASSEMBLED WELDED NMG PAINTED	1
ITEM NO	PART NO	DESCRIPTION	QTY	ITEM NO	DESCRIPTION	QTY	ITEM NO	DESCRIPTION	QTY	ITEM NO	DESCRIPTION
NOTES: 1. USE ANTI-SEIZE KLINGE P/N K13-02069-00 ON ALL STAINLESS STEEL FASTENERS 2. SEE W/ #157 FOR CONTROL BOX ENGINE HARNESS CONNECTIONS, AND TO SECURE HARNESS											
UNCONTROLLED IF PRINTED											
KLINGE CORPORATION 4075 EAST MARKET STREET, YORK, PA 17402 USA UNIT GENSET NMG-TIER 4 ISUZU ENGINE/RFL ALTERNATOR 18 KW											
DRAWING NO. 0K011 SCALE N/A SHEET 1 OF 9 SHEET SIZE A2											
REV. 2022/011 F 460-18902-00											

460-18902-00

































360-18951-00