

# KLINGE



## MODEL NMG-118-T4

### OPERATION, SERVICE AND PARTS MANUAL



Address: 4075 East Market Street York, PA 17402-5100 USA

Telephone: 717-840-4500    Telefax: 717-840-4501

[www.klingecorp.com](http://www.klingecorp.com)

MANUFACTURED BY KLINGE CORPORATION



# Table of Contents

Service Request.....	4
Spare Parts Request .....	4
Use of this Manual .....	4
<b>SECTION 1 SPECIFICATIONS .....</b>	<b>5</b>
1.1 GENERAL.....	5
1.2 CONSTRUCTION.....	5
1.3 ENGINE.....	5
1.4 ALTERNATOR.....	5
1.5 TEMPERATURE OPERATING RANGE .....	5
1.6 WEIGHT.....	5
1.7 MOUNTING .....	5
1.8 FUEL SUPPLY .....	5
1.9 POWER SUPPLY .....	6
1.10 CONTROLS.....	6
1.11 ELECTRICAL STARTING SYSTEM .....	6
1.12 FUEL SYSTEM.....	6
1.13 LUBRICATION SYSTEM.....	6
1.14 COOLING SYSTEM .....	7
1.15 COMBUSTION AIR CLEANING SYSTEM.....	7
<b>SECTION 2 SAFETY PRECAUTIONS.....</b>	<b>8</b>
2.1 ROTATING HAZARDS .....	8
2.2 BATTERY HAZARDS .....	8
2.3 NOISE HAZARD.....	8
2.4 ELECTRICAL HAZARDS .....	8
2.5 GENERAL SAFETY PRECAUTIONS .....	9
2.6 SAFETY DO'S AND DON'TS .....	10
<b>SECTION 3 GENERATOR SET OPERATION.....</b>	<b>11</b>
3.1 PRE-START INSPECTION .....	11
3.2 STARTING THE UNIT .....	11
3.3 AFTER START CHECK-UP .....	11
3.4 SHUTTING OFF THE ENGINE .....	11
3.5 LED INDICATORS.....	12
3.6 ENGINE SPEED (RPM) .....	12
<b>SECTION 4 MAINTENANCE AND COMPONENT INFORMATION.....</b>	<b>14</b>
4.1 FUEL SYSTEM.....	14
4.2 COMBUSTION AIR INTAKE SYSTEM .....	14
4.3 LUBRICATION.....	14
4.4 COOLING SYSTEM .....	14
4.5 FAN BELT.....	15
4.6 BATTERY .....	15
4.7 STARTER AND BATTERY CHARGING ALTERNATOR.....	15
4.8 SERVICING SCHEDULE .....	16
4.9 PTI FORM.....	16
<b>SECTION 5 TROUBLESHOOTING .....</b>	<b>17</b>
5.1 TROUBLE SHOOTING.....	17
5.2 POWER VIEW DISPLAY .....	20
<b>SECTION 6 SERVICE PARTS.....</b>	<b>25</b>

## **Service Request**

Requests for Service should be directed to the Klinge Service Team. The below link should be used to place all requests for service and will afford the quickest response time.

<https://klingecorp.com/request-service/>

This form will help us determine model and age of the equipment, location, basic details about the issue, who to contact and how to best handle the issues with the equipment. A service ticket number will be provided in a response email once the form is received and processed. If the equipment is out of warranty, charges may apply for extensive technical support.

Additionally, our Service Department can be reached via email at [technical@klingecorp.com](mailto:technical@klingecorp.com).

## **Spare Parts Request**

Requests for Spare Parts should be directed to our Parts Department via email at [spares@klingecorp.com](mailto:spares@klingecorp.com). Please have available at the time of the request the Serial Number of the equipment to ensure that the proper part is provided.

## **Use of this Manual**

The use of this manual is intended for the safe operation of the equipment described. It is therefore reasoned that persons who have the occasion to use this manual have a knowledge of mechanical and electrical systems and components addressed by its' contents. However, efforts have been made to enable persons less familiar with these systems to use this manual.

The equipment may be installed in a number of configurations. Each may have optional items and differing external details provided by third parties. The specific electrical diagram is posted on the unit as decals.

Suggestions as to improvement in content and format are welcome and should be addressed to [engineering@klingecorp.com](mailto:engineering@klingecorp.com). Corrections and improvements will be included on dated revisions – the latest of which will be available upon request.

# **SECTION 1 SPECIFICATIONS**

## **1.1 GENERAL**

The NMG-118-T4 (Nose Mount Generator Set) was specifically designed to meet the rigorous demands of ocean, over-the-road, and rail transport of 20' and 40' refrigerated containers. The NMG-118 can be mounted quickly in the nose of a container, using only four bolts.

The genset meets the EPA T4 regulations as confirmed via extensive testing by the engine manufacturer, Isuzu.

## **1.2 CONSTRUCTION**

Welded aluminum frame  
Aluminum doors and closures  
Stainless steel hardware

## **1.3 ENGINE**

ISUZU 4LE2 Tier 4/Stage 3B  
Liquid cooled diesel, four cylinder; 2.2L; 4 stroke; OHV; direct injected; turbocharged; glow plug assisted Start.  
30 kW (40.2 BHP) @ 1800 RPM rated output

## **1.4 ALTERNATOR**

28.4 kW / 35.5 kVA RFL, specifically designed for starting 3 phase AC electrical motors.  
Single bearing, 10 lead, 1800 RPM, Y 480 volts, 0.8 power factor lagging.  
NOTE: The output voltage is not adjustable but is directly related to the engine's speed.  
Normal readings at 1800 RPM (60 Hz) are between 460 and 500 V.

## **1.5 TEMPERATURE OPERATING RANGE**

From -30°C to +50°C (-20°F to +125°F)

## **1.6 WEIGHT**

- 500 kg (1100 lbs.) without fuel
- 685 kg (1510 lbs.) with full fuel tank

## **1.7 MOUNTING**

Mounting clip in back, 4 bolts in front

## **1.8 FUEL SUPPLY**

The generator set has an incorporated fuel tank with a capacity of 170 L (45 US gallons) that can provide approximately 22 hours of operation under full load.

## **1.9 POWER SUPPLY**

STANDARD: 28 kVA - 460 V AC / 3 phase / 60 Hz  
40 A power circuit breaker  
CEE 17 - 32 A power receptacle

## **1.10 CONTROLS**

- Two toggle switches
  - Start switch: OFF-ON-START
  - Engine speed switch: 1000 RPM-1800 RPM
- Isuzu Power View monitors:
  - ENG RPM
  - OIL PRESS
  - COOL TEMP
  - BAT VOLT
  - ENG TORQ
  - MACH HRS
  - FUEL TEMP
  - FUEL RATE
  - INT MFLD T
  - BOOST PRESS
  - SYS VOLT
  - BOST PRES2

## **1.11 ELECTRICAL STARTING SYSTEM**

- Battery: 12V, Group 31 – 950 CCA @ 0°F
- Battery Charging Alternator: 20 or 35 A, 14 VDC
- Starter Motor: 2.0 kW, 12V Gear Reduction type
- Glow plug assisted start with control resistor

## **1.12 FUEL SYSTEM**

- Pre-Fuel Filter w/Water Sedimenter, paper element type w/drain, remote mount
- Pre-Pump, electrical 12 V fuel supply pump, remote mount
- Main Fuel Filter w/Water Sedimenter paper element type with priming pump, w/drain, remote mount
- Engine integrated fuel pump
- Direct injection cylinders

## **1.13 LUBRICATION SYSTEM**

- Full pressure system with trochoid type Oil Pump, driven from the crankshaft.
- Oil pan made out pressed stamped steel, full sump, with a capacity of 8.4 liter (8.9 U.S. quarts).
- Full flow, spin-on Oil Filter, replaceable paper element type.

## **1.14 COOLING SYSTEM**

- Pressurized liquid (50/50 water / glycol mixture) forced circulation by Centrifugal Pump.
- Thermostat, wax pellet type, opening at 76.5°C (170°F).
- Cooling fan suction type, plastic 6 blades, 400mm (15.75") diameter
- Heavy duty 4 row, 3 pass copper / brass Radiator.
- High coolant temperature switch, normal open, single pole, closing at 105°C (221°F).

## **1.15 COMBUSTION AIR CLEANING SYSTEM**

- One high performance single stage Cyclopac® air filter with extended life dry cartridge and automatic dust and water expelling Vacuator™ Valve.
- Air cleaner restriction indicator for maximum filter life.

## **SECTION 2 SAFETY PRECAUTIONS**

*Safety Glasses should be worn at all times when operating or servicing the Generator Set.*

### **2.1 ROTATING HAZARDS**

1. Keep your hands, clothing, and tools clear of the alternator belt when the generator set is running.
2. If it is necessary to run the generator with a removed cover, be very careful with tools or meters being used in that area to avoid contacting the rotor.

### **2.2 BATTERY HAZARDS**

Few people realize just how dangerous a battery can be.

The electrolyte in a lead acid battery is dilute sulfuric acid (H<sub>2</sub>SO<sub>4</sub>). During charge or discharge functions of a battery, a chemical change takes place within the individual cells that cause the bubbling we see through the filler hole. This gas bubbling is hydrogen and oxygen, and it is **EXPLOSIVE**. If during this gassing action, a means of ignition is present, an explosion could occur. A defective battery may suddenly explode even while standing idle. Added to this danger, consider a fall-out of highly corrosive sulfuric acid caused by the explosion.

### **PRECAUTIONS**

1. Always wear eye protection when servicing batteries. If electrolyte is splashed on the skin or in the eyes, flush immediately under running water. Obtain medical help as soon as possible.
2. When charging batteries, do not remove the vent caps.
3. When disconnecting or reconnecting the generator set battery make sure the ON/OFF switch is in the **OFF** position to prevent an arc, which could cause the battery to explode. Disconnect the ground cable first, preferably at a point away from the battery. Reconnect the ground cable last, again away from the battery if possible.
4. **DO NOT** check a battery by "**sparking**" across the posts. Eye injury from the arc or explosion may occur.

### **2.3 NOISE HAZARD**

When servicing or operating the Generator Set in a running condition, personal protective hearing equipment should be worn when exposure is longer than 8 hours.

### **2.4 ELECTRICAL HAZARDS**

#### **HIGH VOLTAGE**

When servicing or repairing a generator set, the possibility of serious or even fatal injury from electrical shock exists. Extreme care must be used when working with an operating generator. Lethal voltage potentials can exist on connections that are in the exciter control box.

Special attention should be given to the Main Power Plug and Receptacle when disconnecting from each other. When disconnecting these two items ensure that the power circuit breaker has been turned to the off position. Do not pull at the cable but rather with a firm grip on the housing, grab the plug and receptacle and pull apart. If the cable is used rather than the housing the risk



exists that the wires within the housing could become dislodged and lead to a future electrical hazard.

## PRECAUTIONS

1. When working on high voltage circuits on the generator sets, **DO NOT** make any rapid moves. If a tool drops, **DO NOT** grab for it. People do not contact high voltage wires on purpose. It occurs from an unplanned movement.
2. Make sure of your footing. If you slip, you will instinctively grab for support. This can be lethal around a generator set. Work on rubber mats or dry wood if possible.
3. Use tools with insulated handles that are in good condition. Never hold metal tools in your hand if exposed energized conductors are within reach.
4. Treat all wires and connections as high voltage until a meter and wiring diagram show otherwise.

**IMMEDIATE ACTION** must be initiated after a person has received an electrical shock. Obtain expert medical assistance if available.

Immediately remove the source of shock by either shutting it down or removing the victim from the source. If it is not possible to shut off the generator set, the wire should be cut with an insulated tool (e.g. a wooden handled axe or cable cutters with heavy insulated handles), or a rescuer wearing insulated gloves. Whichever method is used, **DO NOT** look at the wire while it is being cut. The ensuing flash can cause blindness. Remember that insulated gloves **MUST BE** insulated and not just rubber gloves manufactured for protection from liquids. If the victim has to be removed from live circuitry, pull him off with a non-conductible material. Use his coat, a rope, a piece of dry wood or loop your belt around his leg or arm and pull him off. **DO NOT TOUCH THE PERSON**, you could receive a shock from current flowing through his body. After separating the victim from the power source, check immediately for respiration and presence of pulse. If a pulse is present, respiration might be restored by mouth-to-mouth resuscitation.

## LOW VOLTAGE

Control circuits utilized by the generator set are low voltage (12 VDC). This voltage potential is not considered dangerous, but the large amount of current available (over 300 amps) can cause severe burns if shorted to ground.

1. Disconnect the negative terminal of the battery if possible when working on the generator set. Disconnect the cable end that is away from the battery.
2. **DO NOT** wear jewelry, watches, or rings. These items can short out and cause severe burns to the wearer.

## 2.5 GENERAL SAFETY PRECAUTIONS

1. To prevent against a possible personnel burn injury the following precautions should be followed:
  - a. Do not touch the muffler, exhaust pipe or exhaust manifold while the unit is in operation or immediately after stopping the unit. The unit should be allowed to cool to an acceptable level prior to performing service in these areas.
  - b. Do not touch the radiator cap or attempt to add coolant to the engine while the unit is in operation or immediately after stopping the unit. The unit should be allowed

- to cool to an acceptable level prior to opening the radiator cap.
2. Use extreme caution if holes are drilled into the generator set. Holes drilled into an electrical wire can cause fire, explosion, or shock hazard.
  3. Ensure all mounting screws are tight and are the correct length.
  4. Keep tools and equipment clean and in good working condition. Accidents occur when you attempt procedures without the proper tools.

## **2.6 SAFETY DO'S AND DON'TS**

### **DON'T -**

**DON'T** allow inexperienced personnel to work on the generator or electrical equipment.

**DON'T** remove guards or protective devices.

**DON'T** wear loose clothing or jewelry in the vicinity of moving parts. These can get in machinery, with disastrous results.

**DON'T** wear jewelry while working on electrical equipment. If your hair is long, wear a head covering. Hair caught in a drill press, fan belt or other moving part can cause serious injury.

**DON'T** stand on a wet floor while working on electrical equipment. Use rubber insulated mats placed on dry wood platforms.

**DON'T** lunge after a dropped tool. To do so may place you in a position of extreme danger.

**DON'T** commence any operation until you have taken all the necessary steps to ensure that you are in complete safety.

### **DO -**

**DO** perform your tasks carefully, without undue haste.

**DO** provide fire extinguishers (rated ABC).

**DO** provide a First Aid Kit (for burns and abrasions). Obtain medical attention, if necessary.

**DO** use the correct tools for the job you are doing.

**DO** make sure that all fasteners are secure.

**DO** use extreme care while making adjustments on the generator set while it is running.

**DO** keep your hands away from moving parts.

**DO** remember - Horseplay is for horses! It has no place around machinery.

**DO** disconnect batteries before starting work on the generator set.

**DO** use screwdrivers, pliers, diagonal pliers, etc. with insulated handles.

**DO** remember to keep one hand in your pocket if it is necessary to work on "**live**" circuits. To do so will prevent passage of electricity into one hand and out the other, which passes current across the heart.

**DO PRACTICE SAFETY. THE LIFE YOU SAVE MIGHT BE YOUR OWN**

## **SECTION 3 GENERATOR SET OPERATION**

### **3.1 PRE-START INSPECTION**

1. Check fuel level - Use Diesel fuel SAE No. 2-D, No. 1-D in cold weather, or any other equivalent low sulphur content diesel fuel as DIN EN 590; BS 2869 Class A-1; JIS No.2; NATO Code F-54 / F-34 / F-44 and XF-63.
2. Check engine oil level – should be at full mark  
Use SAE multi-grade oil 10W-40 API rating CC/CD or higher for normal operation and SAE 5W-20 when operating at temperatures below -4°F (-20°C).
3. Check coolant level – should be between the two marks on the overflow bottle.
4. Check fan belt for tension and integrity.
5. Make sure that the generator’s main circuit breaker located in the window of the genset left-hand door is in “OFF” position (right).
6. Ensure the refrigeration unit plug is connected to the generator set power receptacle.

### **3.2 STARTING THE UNIT**

1. Ensure the Engine Speed Switch is set to 1000 RPM.
2. Move the OFF-ON START switch to ON, when the PREHEAT LED goes out (will not illuminate in warmer ambient conditions) toggle the switch to START. Release the switch when the engine has started.
3. Allow the engine to run for a minimum of 10 seconds to become stable at 1000 RPM.
4. Change engine speed switch to 1800 RPM.

### **3.3 AFTER START CHECK-UP**

Look for the following in the Power View window:

- ENG RPM = 1800 ±5
- BAT VOLT = 12.8 VDC or greater
- OIL PRESS = 2 BAR or higher

When the above conditions are met it is safe to switch the main circuit breaker to ON.

There are several safety devices employed to prevent damage to the engine, or the electrical system, should a potentially dangerous situation occur.

The 25 A circuit breaker protects DC components and wiring from a short circuit situation. The circuit breaker will reset periodically until the short circuit is removed.

**WHEN A DC CIRCUIT BREAKER IS REPLACED IT MUST BE INSTALLED PROPERLY WITH THE “BAT” TERMINAL CONNECTED TO THE LINE OR BATTERY SIDE OF THE CIRCUIT AND THE “AUX” TERMINAL CONNECTED TO THE LOAD SIDE OF THE CIRCUIT AS INDICATED ON THE CIRCUIT BREAKER.**

Two safety shutdown devices are used to protect the engine. One is the high temperature switch that actuates at 221°F (105°C). The other is an oil pressure switch that actuates at 14 psi (1kg/cm<sup>2</sup>).

### **3.4 SHUTTING OFF THE ENGINE**

Switch the engine speed to 1000 RPM and allow to run for 3 minutes before switching the start switch to OFF. This will give time for the turbo to cool, extending the life of the turbo/engine.

### **3.5 LED INDICATORS**

The electrical control system is provided with a high intensity red LED located on the upper front of the control box.

This red LED indicates when it is safe to start the engine, based on the temperature following the system's use of glow plugs in low ambient temperature conditions.

### **3.6 ENGINE SPEED (RPM)**

The engine must be set to run at 1000 RPM at start-up.

After allowing the engine to run for 10 seconds to warm up the turbo, the engine speed switch is to be set to 1800 RPM before a load is put on genset.



# **SECTION 4 MAINTENANCE AND COMPONENT INFORMATION**

## **4.1 FUEL SYSTEM**

The fuel injection pumps and fuel injection nozzles are precisely manufactured and therefore using fuel which contains water or dust particles will result in equipment seizure, costly damages and decreased engine output.

Replace fuel filter element after every 500 hrs of operation.

Use KLINGE K26-25310-08 pre-filter element and K26-25310-09 main filter element.

Before starting the unit check for leaks and for water in the filter bowl. Drain if necessary.

Use SAE No.2-D Diesel fuel, 1-D in cold weather.

The following standards are also approved: DIN EN 590; BS 2869 Class A-1; JIS No.2; NATO Code F-54 / F-34 / F-44 and XF-63.

### **DO NOT USE:**

- Diesel fuel that has been contaminated with engine oil, this can cause engine damage and can also affect emission control.
- Fuel additives, except “Biocide” type, if required.

## **4.2 COMBUSTION AIR INTAKE SYSTEM**

Engine performance and life depends on the intake air condition.

Replace air filter cartridge after every 500 hours of operation.

Use KLINGE K26 25091 08 filter cartridge.

After 100 hours of operation, or more often if the generator set is operated in a dusty environment, remove the filter cartridge and blow air at a pressure of 3 – 6 BAR (45 –70 PSI) only from the inside, to remove the dust.

Take care to not damage the filter element during the cleaning and to not cause air leakage (sucking) when the air cleaner is reassembled.

## **4.3 LUBRICATION**

A correct oil and filter service will ensure good performance and a long engine life.

Change oil and filter after initial 50 hours of operation.

Afterwards change the oil every 250 hours and filter every 500 hours of operation or at least once in a year.

Use SAE multi-grade oil SAE 10W-40 API rating Cj-4 or higher and SAE 5W-20 when operating at temperatures below -20°C (-4°F).

Use KLINGE XB-998209 filter element.

Check the oil level before every start, add oil if required, up to the FULL mark.

**CAUTION:** Never mix up different brand or different type of oils.

## **4.4 COOLING SYSTEM**

Use 50/50 Ethylene Glycol / Water solution. Never exceed 60 / 40 antifreeze water mix.

NOTE: Concentrations over 65% Ethylene Glycol adversely affect freeze protection, heat transfer rates and silicate stability that may cause water pump leakage.

Replace coolant every two years.

Check the hoses and pump for leaks and the coolant level, before every trip of the unit. With a cool engine the liquid level should be between the two marks on the expansion tank.

#### **4.5 FAN BELT**

Check the fan belt for tension and integrity before every start.

Replace if necessary, using KLINGE K26 25310-20 belt.

#### **4.6 BATTERY**

Keep the battery fully charged all the time, it is important especially in cold seasons.

Keep the battery posts clean and the battery cables tightened securely.

Always disconnect the battery negative cable when work on the unit is performed.

If distilled water is needed to be added, do it before the unit will be operated, otherwise the water will not mix with the acid and can freeze in cold weather.

#### **4.7 STARTER AND BATTERY CHARGING ALTERNATOR**

The starter and the battery charging alternator servicing consists of:

- Check the carbon brushes and the brush contact.
- Clean the alternator slip ring.

Avoid spraying water or steam on the alternator and on the starter, it may cause damage.

## 4.8 SERVICING SCHEDULE

	Daily or Weekly	Initial 50 Hours	Every 250 Hours	Every 500 Hours	Every 1000 Hours	Every 2000 Hours
<b>GENERATOR SET (NMG-118)</b>						
Check Fuel Level / add if needed	X					
Check sediment bowl on fuel filter (Drain water and clean if needed)		X	X			
Replace Fuel Filter				X		
Replace Air Filter Insert (More frequent may be required based on operating area)				X		
Check Oil Level / add if needed	X					
Replace Oil Filer		X		X (Min Yearly)		
Replace Oil		X	X (Min Yearly)			
Check for fluid leaks	X	X				
Check radiator coolant level/ add if needed	X					
Inspect and if needed clean radiator fins			X			
Flush radiator and replace coolant and hoses						X
Inspect and adjust cooling fan V-belt		X	X			
Replace V-belt						X
Inspect and clean Vacuator valve (Air Filter)			X			
Check engine for unusual noises or exhaust smoke	X		X			
Ensure battery terminals are tight			X			
Check main circuit breaker plastic boot			X			
Inspect unit and generator set for damaged, loose, or broken parts, missing bolts			X			
Check condition of mounting bolts		X	X			
Check condition of engine and alternator mounts (replace if necessary)		X			X	

- In addition to the above checklist the normal Pre-Trip Inspection Form should also be completed every 2 months.

## 4.9 PTI FORM

It is important that a Pre-Trip Inspection (PTI) be completed prior to each shipment.

The NMG-118-T4 PTI form can be found on Klinge's website at:

<http://www.klingecorp.com/pti/>



# **SECTION 5 TROUBLESHOOTING**

## **5.1 TROUBLE SHOOTING**

The following trouble shooting chart is by no means complete, but covers the more general type problems, which would most likely occur if a breakdown is experienced.

<b>POSSIBLE CAUSE</b>	<b>CORRECTIVE ACTION SUGGESTED</b>
-----------------------	------------------------------------

---

**Problem: Engine starter will not energize**

Loose or corroded battery terminals	Clean terminals and tighten
Battery voltage too low	Recharge or replace battery
Faulty START / PREHEAT switch	Replace
Faulty ON / OFF switch	Replace
Faulty starter solenoid	Replace
Faulty starter motor	Replace
Circuit breaker open	Replace if it does not reset

---

**Problem: Starter turns but engine does not ignite**

Faulty control relay R1	Replace
Faulty emergency stop timer	Replace
Faulty engine fuel solenoid	Replace
Control rack is stuck in stop position	Remedy
Engine too hot and protection system will not allow to operate	Allow engine to cool
Faulty coolant temperature switch	Replace switch
Faulty electrical fuel pump	Replace
No fuel	Add fuel to tank
Clogged fuel filter element	Replace

---

<b><u>POSSIBLE CAUSE</u></b>	<b><u>CORRECTIVE ACTION SUGGESTED</u></b>
------------------------------	---

**Problem: Engine starts but stalls immediately**

Air in the fuel system	Remedy and bleed the system
Defective oil pressure switch Low oil pressure LED stays ON	Replace switch
Oil level too low	Add oil

---

**Problem: Engine stops with high engine temperature indication**

Coolant temperature too high	Check cooler for air flow restriction and clean or remove restriction
Coolant level too low	Add coolant
Defective high temperature switch	Replace switch
Thermostat malfunction	Replace
Fan belt slippage or broken	Remedy or replace

---

**Problem: Black exhaust**

Clogged air filter	Clean the filter cartridge or replace
Improper fuel – low cetane grade	Replace fuel
Nozzle damage	Repair or replace nozzle

---

**Problem: White smoke**

Water mixed in fuel	Replace fuel and clean fuel filter
Low compression pressure	Check compression
Low coolant temperature	Check thermostat and replace if needed

---

**Problem: Unstable engine running (Hunting)**

Defective governor spring	Replace
Incorrect valve adjustment	Adjust valve clearance

---

**POSSIBLE CAUSE****CORRECTIVE ACTION SUGGESTED****Problem: No voltage at power receptacle but AC voltmeter needle is in the green band**

---

Main circuit breaker is on OFF position

Turn main circuit breaker ON

Defective main circuit breaker

Replace

---

**Problem: No AC voltage**

No residual magnetism in the alternator exciter field

Restore magnetism by flashing field

Open in main stator windings

Check for continuity in windings

\* Open or short in rotating diodes

Check rotating diodes and replace if needed

\* Open in alternator field

Check for continuity. If field coils are open, replace the rotor or repair it.

\* Shorted exciter armature

Check for short and replace if faulty. Use a Kelvin type bridge to measure this resistance

\* Shorted leads between exciter armature and generator field

Test and repair

NOTE: \* Designated rotating parts. The rear alternator cover (bearing carrier) must be removed in order to perform the test.

For instructions how to perform the tests see “ALTERNATOR MANUAL” at the end of this Manual.

---

**Problem: Low voltage**

Low speed

Check engine speed or system for overload.

Excess load

Reduce load. The load on each leg should be as evenly balanced as possible and should not exceed the rated current on any leg.

High resistance connections –  
Connections will be warm or hot

Make better connections, electrically and mechanically.

Shorted field

Test field coils for possible short. Use an Ohmmeter or resistance bridge. Repair or replace rotor if alternator field coils are shorted.

**POSSIBLE CAUSE****CORRECTIVE ACTION SUGGESTED****Problem: Fluctuating voltage**

Irregular engine speed	Check engine for malfunction.
Loose terminal or load connections	Make better connections.
Defective bearing causing uneven gap	Replace alternator bearing.

**Problem: Overheating**

Generator overloaded	Reduce load. Check with ammeter and compare with alternator nameplate rating.
Unbalanced load	The load on each leg should be as evenly balanced as possible and should not exceed the rated current on each leg.
Dry bearing	Replace bearing
Clogged vent ducts	Clean air passages

**5.2 POWER VIEW DISPLAY****SUPPORTED PARAMETER NUMBERS (SPN)**

The following Parameters are supported and would be displayed if a fault occurs.


SPN	Description
22	Extended Crankcase Blow-by Pressure
51	Throttle Valve 1 Position
52	Intercooler Temperature
92	Engine % Load at Current RPM
94	Fuel Delivery Pressure
96	Fuel Level 1
98	Engine Oil Level
100	Engine Oil Pressure
101	Crankcase Pressure
102	Intake Manifold 1 Pressure

105	Intake Manifold 1 Temperature
106	Air Inlet Pressure
107	Air Filter 1 Differential Pressure
108	Barometric Pressure
109	Engine Coolant Pressure 1
110	Engine Coolant Temperature
111	Engine Coolant Level 1
157	Fuel Injector Metering Rail 1 Pressure
167	Charging System Voltage
168	Battery Potential Voltage
172	Air Inlet Temperature
173	Exhaust Temperature
174	Fuel 1 Temperature
175	Engine Oil Temperature
177	Transmission Oil Temperature
182	Trip Fuel
183	Fuel Rate
184	Instantaneous Fuel Economy
185	Average Fuel Economy
190	Engine Speed (RPM)
247	Engine Hours
441	Aux Temperature 1
513	Actual Engine % Torque
515	Engine Desired Operating Speed (RPM)
701	Aux I/O 1
975	Engine Fan 1 Estimated Speed

1387	Aux Press 1
1436	Engine Ignition Timing
1761	SCR Catalyst Tank Level 1 (DEF)
3031	DEF Tank Temperature
3242	DPF Intake Temperature
3246	DPF Outlet Temperature
3517	SCR Catalyst Tank Level 2 (DEF)
3697	Diesel Particular Filter (DPF) Lamp Status
3698	Exhaust System High Temp Lamp
3700	DPF Active Regeneration Status
3702	DPF Active Regeneration Inhibited
3719	DPF Soot Load %
3720	DPF Ash Load %
5078	Amber Warning Lamp Status
5079	Red Stop Lamp Status
5080	Malfunction Lamp Status
5082	Oil Pressure Low Lamp
5083	Coolant Temperature High Lamp
5245	Diesel Exhaust Fluid Low Level
5246	SCR Operator Inducement
6709	Speed High Lamp

### DATA TROUBLE CODE (DTC)

- Fault codes will be displayed on a dedicated faults page sorted by SPN and FMI code (see image below) **The viewer does not shut the engine down** on fault condition, all shutdowns will be generated by the engine ECM.



- SPN = Suspect Parameter Number - Indicates what part of the system is reporting an error. See Supported Parameters section for a partial list of SPN definitions. Contact equipment manufacturer for a full list.
- FMI = Failure Mode Indicator - Indicates the reported failure. See table below.
- OC = Occurrence Count - how often the failure occurred.
- Address - The source address (SA) of the device reporting the failure. For the NMG-118 T4, SA 0 is the only applicable address, originated by the engine ECU.

FMI	Description
0	Above Normal - Most Severe Level
1	Below Normal - Most Severe Level
2	Data Erratic or Incorrect
3	Voltage Above Normal or Shorted High
4	Voltage Below Normal or Shorted Low
5	Current Below Normal or Open Circuit
6	Current Above Normal or Shorted
7	Mechanical System not Responding or Out of Calibration
8	Abnormal Frequency or PWM Rate
9	Abnormal Update Rate
10	Abnormal Rate of Change
11	Problem Unknown
12	Bad ECM, Controller, or Smart Sensor
13	Out of Calibration
14	Special Instructions
15	Above Normal - Least Severe Level
16	Above Normal - Moderately Severe Level
17	Below Normal - Least Severe Level
18	Below Normal - Moderately Severe Level
19	CAN Data Error
20	Data Drifted High

21	Data Drifted Low
22 - 30	Reserved for Future Use
31	Condition Exists



## **SECTION 6 SERVICE PARTS**

### **LIST OF CONTENTS**

<b>Unit Genset NMG-Tier 4 Isuzu Engine/RFL Alternator 18 kW</b>	<b>26</b>
<b>Engine / Alternator Assembly Tier 4</b>	<b>35</b>
<b>Box Control</b>	<b>42</b>
<b>Alternator RFL-30 Modified</b>	<b>44</b>
<b>Box Accessories Power Alarm &amp; GSM Complete (Optional)</b>	<b>45</b>


1	2	3	4	5	6	7	8	9	10	11	12				
DRAWING NO.	REV.	DATE	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION	QTY	ITEM NO.	PART NO.	DESCRIPTION	QTY				
460-18902-00	D	20230417	ITEM #40 QTY WAS 45 (INCHES) ITEM #41 WAS XB-99067 QTY 8 ITEM #47 QTY WAS 36 ITEM #48 QTY WAS 14 ITEM #53 QTY WAS 61 ITEM #56 QTY WAS 20 ITEM #62 QTY WAS 9 ITEM #63 QTY WAS 11 ITEM #67 QTY WAS 11 ITEM #68 QTY WAS 36 ITEM #75 WAS K21-50227-90 ITEM #84 QTY WAS 6 ITEM #85 QTY WAS 11 ITEM #94 WAS K26-25691-02 ADDED ITEM #104 ITEM #105 WAS K21-16218-00 ITEM #106 WAS K21-18426-02 QTY 1 ADDED ITEMS #110 SHEET 5, ADDED #111 SHEET 3, ADDED SECTION BD-DETAIL SHEET 3, ADDED "AIR INTAKE TEMPERATURE SENSOR" AND AIR FLOW AT "PVC HEATER" SHEET 5, UPDATED FUEL LINES	118	K21-16548-09	CLAMP CS VINYL COATED 0.812" ID 3/4" WIDE	2	78	K21-16583-20	NUT LOCK SS M10 X 1.5 NYLON INSERT	12	40	XB-998090	TUBE PVC CLEAR 5/16 ID (INCHES)	90
	E	20230612	ITEM #56 QTY WAS 9 ITEM #60 QTY WAS 15 ITEM #73 QTY WAS 1 ITEM #74 QTY WAS 15 ITEM #85 QTY WAS 4 ITEM #103 QTY WAS 12 ADDED ITEMS #112 THRU #118 ADDED NOTE #2, UPDATED FUEL LINE HOSE LENGTHS SHEET 7 REMOVED ITEM #108 (360-18978-00) ITEM #109 WAS K21-15649-04 SHEET 7	119	K21-15797-04	WASHER LOCK EXT INT SS #10	1	79	K21-16583-30	NUT LOCK SS M10 X 1.5 NYLON INSERT	6	39	060-18893-00	HOSE RADIATOR INLET DAYCO	1
	F	20240111	DO NOT SCALE	120	K21-16547-10	WASHER FLAT, STAINLESS STEEL, M10 X 30 X 2.5	1	79	K21-16583-30	NUT LOCK SS M10 X 1.5 NYLON INSERT	6	39	060-18893-00	HOSE RADIATOR INLET DAYCO	1
				121	K21-16583-12	WASHER FLAT, STAINLESS STEEL, M12 X 37 X 3	1	77	K21-16547-10	WASHER FLAT, STAINLESS STEEL, M10 X 30 X 2.5	1	38	060-18894-00	HOSE RADIATOR OUTLET NMG TIER 4	1
				122	K21-16583-12	NUT LOCK SS M12 X 1.75 NYLON INSERT	1	76	K21-16583-12	NUT LOCK SS M12 X 1.75 NYLON INSERT	1	37	060-14473-00	HOLDER RADIATOR OUTLET HOSE NMG-115-10	1
				123	K21-50227-80	SCREW HEX SS M12 X 1.75 X 80 18-8 PARTIAL THREAD	1	75	K21-50227-80	SCREW HEX SS M12 X 1.75 X 80 18-8 PARTIAL THREAD	1	36	360-14506-02	CABLE BATTERY NEGATIVE BLACK BOOT, 4 INCH LG	1
				124	K21-50401-01	WASHER FLAT, STAINLESS STEEL, M10 X 20 X 2	1	74	K21-50401-01	WASHER FLAT, STAINLESS STEEL, M10 X 20 X 2	1	34	360-14506-02	CABLE BATTERY POSITIVE RED BOOT 4 INCH LG	1
				125	K21-50226-25	SCREW HEX SS M10 X 1.5 X 20 LONG 18-8 FULL THREAD	2	73	K21-50226-25	SCREW HEX SS, FULL THREAD, M10 X 1.5 X 25	2	33	XB-993011-02	RUBBER PAD - BATTERY 3.0W X 12.0MM LG	2
				126	K21-50421-05	WASHER LOCK SPG SS M5 X 9.2 X 1.2 THK	1	72	K21-50421-05	WASHER LOCK STAINLESS STEEL, 5/16 X 0.88 X 18-8	1	32	K25-25912-00	BATTERY 12 VOLT, TOP STUDS WITH NUTS	1
				127	K26-25310-03	FUEL LOW PRESSURE PUMP (SUZUKI NMG TIER-4)	1	71	060-14493-00	BRACKET SS BATTERY HOLD-DOWN	1	31	360-18911-01	BRACKET FUEL MAIN FILTER PAINTED	1
				128	K26-24666-00	INDICATOR AIR RESTRICTION 20" H2O	1	70	K21-164921-07	NUT LOCK, STAINLESS STEEL, 5/16 - 18	2	30			1
				129	K21-15649-08	CLAMP CUSH SS 3/4 IN ID, 28 MOUNTING HOLE	2	69	XB-2099049	ROD BATTERY HOLD DOWN NMG-115-10	2	29			1
				130	360-18970-00	BOX BREAKER (TOP MOUNT)	1	68	K21-50421-08	WASHER LOCK, SPRING, SS, M8 X 15 X 4 X 2	4	28	360-18922-00	BOX CONTROL WHITE	1
				131	K21-13427-14	FITTING 90 DEG 3/8 HOSE 1/4MM BANJO	1	67	K21-50401-08	WASHER FLAT, STAINLESS STEEL, M8 X 17 X 1.4-1.8	4	27	XB-993000-18	RUBBER NEOPRENE 1/8" X 10" X 4.0"	2
				132	K21-16686-10	CLAMP OETIKER SS DOUBLE PINCH (15-18MM)	8	66	K21-50225-25	SCREW HEX SS M8 X 125 X 25 LONG 18-8 FULL THREAD	15	26	XB-205126	BRACKET ASSEMBLY RADIATOR HOLD-DOWN	1
				133	K28-10804-06	HOSE NEOPRENE PUSH LOCK BLACK (QTY IN FT)	9	65	K21-16245-25	WASHER FLAT SS H8	1	25	XB-993011-03	RUBBER 3/16 X 3.0 X 9.0	2
				134	K29-18490-00	HOOK STRAP SS 0.125 DIA. WIRE	6	64	K21-164921-02	NUT LOCK SS NO 8-32 18-8	1	24	XB-34005	RADIATOR 4 ROW / 3 PASS NMG ISUZU ENG	1
				135	K28-10891-00	STRAP 15" LG NO HOOKS	3	63	K21-50401-06	WASHER FLAT, STAINLESS STEEL, M6 X 12 X 1.4-1.8	2	23	060-18855-00	SHROUD FAN ASSEMBLY TIER 4 NMG	1
				136	K28-10797-00	GROMMET 175X175X1875	1	62	K21-164921-06	STUD FLUSH M6 X 1.0 X 30MM LG	2	22	060-18853-01	ANGLE RADIATOR TOP SUPPORT PAINTED	1
				137	K26-25095-04	HOOD AIR INLET PLASTIC STYLE E FITS 2.50 OD FILTER	1	60	K21-50421-10	WASHER LOCK, SPRING, SS, M10 X 18 X 4 X 2.5	18	20	060-18850-01	POST REAR RADIATOR SUPPORT NMG TIER-4	1
				138	K28-11555-00	HOSE ADAPTER PCV VENT TUBE	1	59	K21-18510-08	WASH INSUL PVC M8 25/48.4MM OD/ID 0.02 IN 0.51MM	36	19	360-11014-00	CLIP RETAINING	1
				139	K28-11154-00	ELBOW 90 DEG 1.50" - 2.00" ID, SILICONE	1	58	K21-50225-30	SCREW HEX SS M8 X 125 X 30 18-8 FULL THREAD	6	18	060-18943-01	RETAINER POWER CABLE PAINTED	2
				140	K28-11556-00	ELBOW 90 DEG 2.00" - 2.25" ID	1	57	K21-164921-06	SCR FLAT SS M8-1.25 X 25 LG	7	17	060-18849-01	ANGLE DIAGONAL SUPPORT TOP PLATE PAINTED	1
				141	K26-24667-00	BAND AIR CLEANER MTG 6.5 ID	2	55	K21-50421-06	WASHER LOCK, SPRING, SS, M6 X 12.2 X 1.5	10	16	360-18847-01	POST ASSEMBLY FRAME REAR PAINTED	1
				142	K26-25095-01	FILTER AIR 1 STAGE 2-1/2 IN - 2-1/4 OUT	1	54	K21-18510-06	WASH INSUL PVC M6 19/67.2MM OD/ID 0.51MM THICK	31	14	360-18844-01	ANGLE TOP REAR PAINTED NMG TIER 4	1
				143	K21-16684-00	CLAMP DUAL LINE 5/8" TO 3/4" OD	1	53	K21-16547-08	WASHER FLAT SS M8 LARGE OD 24MM 18-8 2MM THICK	72	13	360-18842-01	ANGLE TOP FRONT PAINTED NMG TIER-4	1
				144	K21-50226-40	SCREW HEX SS, FULL THREAD, M10 X 1.5 X 4.0	2	51	K21-16583-08	NUT LOCK SS M6 X 1.25 NYLON INSERT	22	11	360-18838-00	PANEL ALTERNATOR END WELDED & PAINTED WHITE	1
				145	K21-11474-00	FITTING 90-DEG BARB 3/8 HOSE 9/16-18 FEMALE	2	49	K21-16231-00	CLAMP HOSE SS 0.75 - 1.50 INCH	2	10	K29-17880-01	HINGE SLIP SS 9/32 HOLES SOCK LT HAND	2
				146	K21-15649-15	CLAMP CUSH SS 32mm=1.25 ID	1	48	K21-50224-18	SCREW HEX SS, FULL THREAD, M6 X 100 X 18	8	9	360-18890-00	PANEL TOP ASSEMBLY	1
				147	K21-10189-00	CLAMP CUSHIONED STAINLESS STEEL 1/2 INCH	2	47	K21-16583-06	NUT LOCK SS M6 X 1 NYLON INSERT	17	8	360-18908-00	DOOR ASSEMBLY RIGHT NMG TIER 4	1
				148	K21-14642-00	WASHER FLAT STAINLESS STEEL 1/4 X 0.28 X 0.63	6	47	K21-16547-06	WASHER FLAT, STAINLESS STEEL, M6 X 18 X 16	29	7	360-18888-00	DOOR LEFT END ASSEMBLY NMG TIER-4	1
				149	K21-50103-06	NUT HEX SS M6 X 1	5	45	XB-995029	SLEEVE WIPER GLASS 1.50 1000 F	32	5	360-18885-00	PANEL ASSEMBLY REAR NMG TIER-4	1
				150	K21-50224-25	SCREW HEX SS, FULL THREAD, M6 X 100 X 25	2	44	K21-16231-00	CLAMP HOSE SS 106" TO 2"	4	4	360-18890-00	ISOLATOR ENGINE NEOPRENE 260 LB AXIAL 130 LB LOAD	4
				151	K21-16528-30	BOLT CARR SS M8 X 1.25 X 30	1	43	360-18895-10	EXHAUST ASSEMBLY NMG TIER 4	1	3	360-18814-02	CRADLE RFL ALTERNATOR BLACK	1
				152	060-09113-00	INSULATOR HINGE	4	42	K23-10280-00	CLAMP HOSE (38 - 63) 5/16 WIDE SS	2	2	360-18874-00	TANK ASSEMBLY FUEL NMG-TIER 4	1
				153	K21-18510-10	WASH INSUL PVC M10 318/10.3MM OD/ID 0.02 IN 0.51MM	8	41	K21-18426-02	CLAMP HOSE SS 125 TO 2 1/2 DIA RANGE	5	1	360-18836-01	FRAME ASSEMBLED WELDED NMG PAINTED	1

**KLINGE CORPORATION**  
 4075 EAST MARKET STREET, YORK, PA 17402 USA  
 UNIT GENSET NMG-TIER 4 ISUZU  
 ENGINE/RFL ALTERNATOR 18 KW  
 DRAWING NO. 460-18902-00  
 SCALE N/A SHEET 1 OF 9

**KLINGE**  
 NAME NWB DATE 2023/01/11  
 DRAWN BES APPROVED BES  
 REV 0K0L1  
 REV 460-18902-00 F

ALL PROPRIETARY INFORMATION IS THE PROPERTY OF KLINGE CORPORATION. ANY REPRODUCTION OR DISSEMINATION OF THIS DOCUMENT WITHOUT THE WRITTEN PERMISSION OF KLINGE CORPORATION IS STRICTLY PROHIBITED. THIS DOCUMENT IS UNCONTROLLED IF PRINTED.

460-18902-00



DRAWING NO.  
460-18902-00


DO NOT SCALE

460-18902-00

<b>KLINGE</b> <small>ALL PROPRIETARY INFORMATION IS THE PROPERTY OF KLINGE CORP. NO PART OF THIS DOCUMENT IS TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM. WITHOUT PERMISSION IN WRITING FROM KLINGE CORP.</small>		<b>KLINGE CORPORATION</b> 4075 EAST MARKET STREET, YORK, PA 17402 USA
MATERIAL NUMBER N/A SUBJECT MATTER N/A DIMENSIONS ARE IN INCHES UNLESS OTHERWISE INDICATED DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE INDICATED LINEAR X.X ± .01 / .02 ANGULAR X.X ± .1 / .25	TITLE <b>UNIT GENSET NMG-TIER 4 ISUZU ENGINE/RFL ALTERNATOR 18 KW</b>	DRAWING NO. <b>460-18902-00</b>
NAME DATE DRAWN APPROVED	DATE 2022/01/11	REV <b>F</b>
CATEGORY <b>0K0L1</b>	SCALE N/A	SHEET SIZE A2

UNCONTROLLED IF PRINTED





DO NOT SCALE

DRAWING NO. 460-18902-00

IF RADIATOR HOSE DOES NOT COME WITH CONDUIT INSTALLED ON IT USE 060-15603-00 HERE

SEE SHEET 7 FOR MOUNTING HARDWARE

APPLY BLUE LOCTITE (K13-03171-00) TO EACH SCREW SUPPLIED WITH ENGINE KIT

EXHAUST MOUNTING HARDWARE


ENGINE MOUNTING HARDWARE

ALTERNATOR FOOT MOUNTING SECTION Y-Y

<b>KLINGE</b> 4075 EAST MARKET STREET, YORK, PA 17402 USA TITLE <b>UNIT GENSET NMG-TIER 4 ISUZU ENGINE/RFL ALTERNATOR 18 KW</b>		DRAWING NO. <b>460-18902-00</b>	REV <b>F</b>
NAME <b>NWB</b>	DATE <b>2022/011</b>	SCALE <b>N/A</b>	SHEET SIZE A2
DRAWN <b>BES</b>	APPROVED <b>2022/017</b>	CASE/DOC# <b>0K0L1</b>	SHEET 4 OF 9
MATERIAL NUMBER N/A SUBJECT MATTER N/A DIMENSIONS ARE DIMENSIONS UNLESS OTHERWISE INDICATED PARTS OF THIS DRAWING ARE THE PROPERTY OF KLINGE CORPORATION AND SHALL REMAIN THE PROPERTY OF KLINGE CORPORATION IF REPRODUCED IN WHOLE OR IN PART WITHOUT THE WRITTEN PERMISSION OF KLINGE CORPORATION.	LINEAR X.X ± / - / + 0.01 ANGULAR X.X ± / - / + 0.5°	MATERIAL N/A SUBJECT MATTER N/A DIMENSIONS ARE DIMENSIONS UNLESS OTHERWISE INDICATED PARTS OF THIS DRAWING ARE THE PROPERTY OF KLINGE CORPORATION AND SHALL REMAIN THE PROPERTY OF KLINGE CORPORATION IF REPRODUCED IN WHOLE OR IN PART WITHOUT THE WRITTEN PERMISSION OF KLINGE CORPORATION.	ALL PROPRIETARY INFORMATION IS THE PROPERTY OF KLINGE CORPORATION. NO PARTS OF THIS DRAWING ARE TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF KLINGE CORPORATION.

460-18902-00

UNCONTROLLED IF PRINTED




<b>KLINGE CORPORATION</b>	
4075 EAST MARKET STREET, YORK, PA 17402 USA	
TITLE	
UNIT GENSET NMG-TIER 4 ISUZU	
ENGINE/RFL ALTERNATOR 18 KW	
DATE	REV
0K0L1	F
BRANNO NO.	460-18902-00
SCALE	SHEET 5 OF 9
N/A	SHEET SIZE A2

<b>KLINGE</b>	
MATERIAL NUMBER N/A	DATE
SIZE N/A	NWB 2022/011
DIMENSIONS ARE IN INCHES! UNLESS OTHERWISE INDICATED	APPROVED
ALL PROPRIETARY INFORMATION IS THE PROPERTY OF KLINGE CORP. NO PERMISSION IS GRANTED TO REPRODUCE OR TRANSMIT IN ANY MANNER, IN WHOLE OR IN PART, OR TO DISCLOSE OR USE ANY INFORMATION CONTAINED HEREIN WITHOUT THE WRITTEN PERMISSION OF KLINGE CORP.	BES 2022/017
LINEAR DIMENSIONS: X, Y, Z = ±0.014 / -0.008	NAME
ANGULAR DIMENSIONS: X, Y = ±1.55°	NWB
	DATE
	2022/011
	DRAWN
	BES

REAR VIEW


UNCONTROLLED IF PRINTED



<b>KLINGE CORPORATION</b> 4075 EAST MARKET STREET, YORK, PA 17402 USA	
<b>UNIT GENSET NMG-TIER 4 ISUZU ENGINE/RFL ALTERNATOR 18 KW</b>	
DRAWING NO. <b>0K01</b>	REV <b>F</b>
NAME <b>NMB</b>	DATE <b>2022/01</b>
DRAWN <b>BES</b>	APPROVED <b>BES</b>
SCALE <b>N/A</b>	SHEET SIZE <b>A2</b>
MATERIAL NUMBER <b>N/A</b>	DIMENSIONS ARE IN INCHES UNLESS OTHERWISE INDICATED LINEAR ANGULAR X.X ± 0.01 / -0.00 X.X ± 0.5°
ALL PROPRIETARY INFORMATION IS THE PROPERTY OF KLINGE CORP. NO PART OF THIS DRAWING IS TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, WITHOUT PERMISSION IN WRITING FROM KLINGE CORP.	UNCONTROLLED IF PRINTED











<b>KLINGER</b> <small>ALL PROPRIETARY INFORMATION IS THE PROPERTY OF KLINGER CORPORATION. NO PERMISSION IS GRANTED TO REPRODUCE OR TRANSMIT THIS INFORMATION IN WHOLE OR IN PART, OR TO DISCLOSE IT TO ANY OTHER PARTY WITHOUT THE WRITTEN PERMISSION OF KLINGER CORPORATION.</small>	MATERIAL NUMBER N/A SUBJECT MATTER SIZE N/A DIMENSIONS SEE DIMENSIONS LIST OR OTHERWISE INDICATED LINEAR X.XX ± 0.01 (± 0.001) ANGULAR XX ± 1.5°	NAME NWB DATE 2022/01/11 DRAWN BES APPROVED BES	TITLE <b>KLINGER CORPORATION</b> 4075 EAST MARKET STREET, YORK, PA 17402 USA <b>UNIT GENSET NMG-TIER 4 ISUZU ENGINE/RFL ALTERNATOR 18 KW</b>	CASE/REV 0K0L1 DRAWING NO. 460-18902-00	REV F
	SCALE N/A SHEET R OF 9		SHEET SIZE A2		
	DRAWING NO. 460-18902-00				

DO NOT SCALE

DRAWING NO.  
460-18902-00





460-18902-00

UNCONTROLLED IF PRINTED

12 11 10 9 8 7 6 5 4 3 2 1

DRAWING NO.  
460-18902-00

DO NOT SCALE




REAR VIEW

<b>KLINGE</b> <small>EST. 1936</small>	<b>MATERIAL</b> NUMBER N/A SPEC. N/A SIZE N/A <small>(DIMENSIONS ARE IN INCHES)          DIMENSIONS ARE IN MILLIMETERS          OTHERWISE INDICATED</small>	<b>KLINGE CORPORATION</b> 4075 EAST MARKET STREET, YORK, PA. 17402 USA
	<b>ALL PROPRIETARY INFORMATION IS UNCLASSIFIED UNLESS INDICATED OTHERWISE BY KLINGE CORP.</b> NO PERMISSIONS GRANTED TO REPRODUCE OR DISCLOSE IN WHOLE OR IN PART, OR DISCLOSE TO OTHERS WITHOUT THE WRITTEN PERMISSION OF KLINGE CORP.	<b>TITLE</b> ENGINE/RFL ALTERNATOR 18 KW
<b>DATE</b> NAME DRAWN APPROVED	<b>DATE</b> NAME DRAWN APPROVED	<b>ENGINE/RFL ALTERNATOR 18 KW</b>
<b>LINEAR</b> X.XX +/- 0.01 +/- 0.01 <b>ANGULAR</b> XX +/- 0.5°	<b>DRAWING NO.</b> 460-18902-00	<b>SCALE</b> N/A
<b>SHEET 9 OF 9</b>		<b>REV</b> F

460-18902-00

UNCONTROLLED IF PRINTED

1	2	3	4	5	6	7	8	9	10	11	12
DRAWING NO. <b>360-18892-00</b>											
DO NOT SCALE											
REV	DATE	DESCRIPTION						CHANGE NO		DRAWN APPROVED	
A	10/11/2022	PLACE HOLDER LINE ADDED FOR ITEM 8						22-228	RJK	BES	
B	20221024	ITEM 8 (GROUND STRAP) ADDED TO BOM. ITEM 12 (ALTERNATOR) PART NUMBER CHANGED.						22-237	RJK	BES	
C	20230405	ITEM #5 WAS K21-16278-00, ITEM #20 WAS #21, ITEM #21 WAS #23, ITEM # 22 WAS #24, ITEM #23 WAS #25, ITEM #24 WAS #26, ITEM #25 WAS #27, ITEM #26 WAS #28, ITEM #27 WAS #29, ITEM #28 WAS #20, ITEM #29 WAS #22, UPDATED FUEL LINE SHEET 6						23-059	DBG	BES	
D	20230612	ITEM #3 QTY WAS 2.13 FT., UPDATED ITEM #3 FUEL LINE HOSE LENGTHS SHIT 6						23-167	DBG	BES	



29	K21-50224-20	SCREW HEX SS M6 X 1 X 20 FULL THD	4
28	K21-50401-06	WASHER FLAT SS M6 6.4 X 12 X 1.4-1.8 18.8 DIN 125	4
27	K26-25310-16	BOLT, HEX WITH WASHER, STAINLESS STEEL, M10 X 1.0 X 25	1
26	K26-25310-14	FITTING, BANJO, FUEL LINE, ISUZU	1
25	K26-25310-15	WASHER, FUEL LINE, SEALING, ISUZU	1
24	XB-302169	BRACKET, OIL DRAIN HOSE	1
23	K21-16681-30	SCREW CAP SOCKET ZINC-ALLOY M10 X 1.5 - 30	6
22	XB-992749	WASHER FLAT, ZINC PLATED, M8	8
21	XB-992659-16	SCREW, HEX, CAP SOCKET, BLACK OXIDE, M8 X 16	8
20	K21-50226-25	SCREW HEX SS M10 X 1.5 X 25 18-8 933 FULL THREAD	3
19	K21-50401-10	WASHER FLAT SS M10 10.5 X 20 X 2 18-8 DIN 125	19
18	K21-50421-10	WASHER, LOCK, SPRING, STAINLESS STEEL, M10 X 18.4 X 2.5	19
17	XB-992610-30	BOLT, HEX, ZINC PLATED, M10 X 30 MM	8
16	XB-999094	CAP, BOTTLE, RADIATOR OVERFLOW	1
15	XB-999093	BOTTLE, COOLANT OVERFLOW	1
14	XB-152043	DECAL, "50/50 ETHYLENE GLYCOL / WATER"	1
13	360-14381-00	SUPPORT OVERFLOW BOTTLE ASSEMBLY NMG BLACK	1
12	360-18951-00	ALTERNATOR REL-30 MODIFIED WITH BREAKER BOX	1
11	360-14518-02	HOSE ASSEMBLY OIL DRAIN ISUZU	1
10	K23-13332-07	FITTING, 90 DEGREE, CARBON STEEL, 7/8 INCH	1
9	XB-998200	FAN, COOLING, SUCTION, PLASTIC, 6 BLADE, ISUZU	1
8	K25-26621-08	STRAP GROUND 8" LG 3/8" MOUNTING HOLE	1
7	360-18668-01	MOUNT ENGINE RIGHT TIER 4 PAINTED	1
6	360-18867-01	MOUNT ENGINE LEFT TIER 4 PAINTED	1
5	K21-16686-10	CLAMP DETIKER SS DOUBLE PINCH (15-18MM)	4
4	K28-11150-00	FITTING 3/8 HOSE BARBED TEE CONNECTOR	1
3	K28-10804-06	HOSE, RUBBER, 3/8 INCH ID, PUSH LOCK (QTY IN FT)	1.96
2	K28-10804-04	HOSE, RUBBER, 1/4 INCH ID, PUSH LOCK (QTY IN FT)	0.75
1	K26-25310-00	ENGINE, ISUZU, 41E27AGV-07 (MODIFIED)	1
ITEM NO	PART NO	DESCRIPTION	QTY

**KLINGE**  
 4075 EAST MARKET STREET, YORK, PA 17402 USA  
 TITLE: **ENGINE ALTERNATOR ASSEMBLY TIER 4**

MATERIAL NUMBER N/A  
 SUBJECT MATTER N/A  
 SIZE N/A  
 DIMENSIONS ARE IN INCHES UNLESS OTHERWISE INDICATED  
 LINEAR X.X.X = +/- .05 (+/- .001)  
 ANGULAR X.X = +/- .5°

ALL PROPRIETARY INFORMATION IS THE PROPERTY OF KLINGE CORP. NO PERMISSIONS ARE GRANTED TO REPRODUCE OR TRANSMIT IN ANY MANNER OR IN ANY MEDIUM WITHOUT THE WRITTEN PERMISSION OF KLINGE CORP.

DATE: 20220429  
 NAME: AUV  
 DRAWN: BES  
 APPROVED: BES


SCALE: N/A  
 SHEET 1 OF 7

REV: D  
 SHEET SIZE: A2

NOTES:  
 1. USE ANTI-SEIZE KLINGE P/N K13-02069-00 ON ALL STAINLESS STEEL FASTENERS

UNCONTROLLED IF PRINTED

360-18892-00



DRAWING NO.  
360-18892-00

ALTERNATOR PRE-ASSEMBLY


DO NOT SCALE

<b>KLINGE</b> <small>EST. 1936</small>	<b>KLINGE CORPORATION</b> 4075 EAST MARKET STREET, YORK, PA 17402 USA	
	TITLE <b>ENGINE ALTERNATOR ASSEMBLY TIER 4</b>	
MATERIAL NUMBER N/A SPEC. N/A SIZE N/A	NAME AUV	DATE 20220429
DIMENSIONS (SEE DIMENSIONS) UNLESS OTHERWISE INDICATED LINEAR X, Y, Z = +/- .031 (+/- .001) ANGULAR X, X' = +/- .5° X, X' = +/- .5°	DRAWN BES	APPROVED BES
ALL PROPRIETARY INFORMATION IS THE PROPERTY OF KLINGE CORP. NO PART OF THIS DOCUMENT IS TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, WITHOUT PERMISSION IN WRITING FROM KLINGE CORP.	CASE/DOC# 0K0L1	DRAWING NO. 360-18892-00
SCALE N/A	SHEET NO. 2 OF 7	REV D


NOTES:  
1. FOLLOW SHEET 3 FOR ENGINE-ALTERNATOR ASSEMBLY

360-18892-00

UNCONTROLLED IF PRINTED



DRAWING NO. <b>360-18892-00</b>		DO NOT SCALE		12	
MATERIAL NUMBER N/A SIZE N/A		KLINGE CORPORATION 4075 EAST MARKET STREET, YORK, PA 17402 USA		TITLE <b>ENGINE ALTERNATOR ASSEMBLY TIER 4</b>	
DIMENSIONS ARE IN INCHES UNLESS OTHERWISE INDICATED LINEAR X.X = +/- .051 (+/- .001) ANGULAR X.X = +/- .5°		NAME AUV		DATE 20220429	
ALL PROPRIETARY INFORMATION IS THE PROPERTY OF KLINGE CORP. NO PERMISSION IS GRANTED TO REPRODUCE OR DISCLOSE THIS INFORMATION TO OTHERS WITHOUT THE WRITTEN PERMISSION BY KLINGE CORP.		DRAWN BES		APPROVED BES	
PART OF DISCLOSE INFORMATION TO OTHERS WITHOUT THE WRITTEN PERMISSION BY KLINGE CORP.		DRAWING NO. 0K0L1		SCALE N/A	
THIS HARDWARE IS FOR THE OVERFLOW TANK BRACKET		DRAWING NO. 360-18892-00		REV D	
ALIGN AND MOUNT THE ALTERNATOR WITH THE MOUNTING STUDS ON THE FLYWHEEL HOUSING USE ITEM 18 & 19		SCALE N/A		SHEET SIZE A2	
ALTERNATOR TO ENGINE TORQUE SPEC: 26Nm (20FT/LBS) (6 PLCS) USE BLUE LOCTITE THREADLOCKER		SCALE N/A		SHEET 3 OF 7	
CENTER SHAFT BOLT TORQUE SPEC: 60Nm - 44.25FT/LB		SCALE N/A		SHEET 3 OF 7	




DO NOT SCALE  
 DRAWING NO.  
**360-18892-00**

<b>KLINGE</b> <small>EST. 1936</small>	<b>KLINGE CORPORATION</b> 4075 EAST MARKET STREET, YORK, PA. 17402 USA	
	<b>ENGINE ALTERNATOR ASSEMBLY TIER 4</b>	
TITLE	DRAWING NO. <b>360-18892-00</b>	REV <b>D</b>
NAME AUV	DATE 20220429	SCALE N/A
DRAWN BES	APPROVED BES	SHEET SIZE A2
MATERIAL NUMBER N/A SUBJECT MATTER N/A SIZE N/A	DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE INDICATED LINEAR X.X ± .05 (+/- .020) ANGULAR X.X ± .1° (+/- .05°)	
ALL PROPRIETARY INFORMATION IS THE PROPERTY OF KLINGE CORPORATION. NO PERMISSION IS GRANTED TO REPRODUCE OR DISCLOSE THIS DRAWING TO ANY OTHERS WITHOUT THE WRITTEN PERMISSION OF KLINGE CORPORATION.		

UNCONTROLLED IF PRINTED

360-18892-00




<b>KLINGE</b> 4075 EAST MARKET STREET, YORK, PA 17402 USA TITLE: <b>ENGINE ALTERNATOR ASSEMBLY TIER 4</b>		DRAWN: <b>AUV</b> DATE: <b>20220429</b>	DRAWING NO: <b>360-18892-00</b> SCALE: <b>N/A</b> SHEET 5 OF 7
ALL PROPRIETARY INFORMATION IS THE PROPERTY OF KLINGE CORP. NO PERMISSION IS GRANTED TO REPRODUCE OR DISCLOSE THIS INFORMATION WITHOUT THE WRITTEN PERMISSION OF KLINGE CORP.	MATERIAL NUMBER: <b>N/A</b> SIZE: <b>N/A</b> DIMENSIONS ARE IN INCHES UNLESS OTHERWISE INDICATED LINEAR: <b>X.XX +/- .031 +/- .001</b> ANGULAR: <b>X.X +/- .5°</b>	NAME: <b>DATE</b> AUV: <b>20220429</b>	APPROVED: <b>BES</b> 20220919

ITEMS TO BE RETAINED FROM THE DISASSEMBLY AND TO BE USED LATER IN THE ASSEMBLY - REFER SHEET 6

1. FUEL BANJO BOLT	-	DETAIL E - STEP 1
2. CLAMPS	-	DETAIL E - STEP 3
3. DUAL BANJO FITTING	-	DETAIL E - STEP 4
4. SEALING WASHERS	-	

UNCONTROLLED IF PRINTED

360-18892-00



DRAWING NO.  
360-18892-00

DO NOT SCALE

**FUEL LINE MODIFICATIONS  
AND  
INSTALLATION INSTRUCTIONS**

<b>KLINGE</b> <small>ALL PROPRIETARY NUMBER N/A SUBJECT MATTER HERE OF ARE NO PERMISSIONS GRANTED TO RE-PARTY OR DISCLOSE INFORMATION TO OTHERS WITHOUT PERMISSION BY KLINGE CORP.</small>		<b>KLINGE CORPORATION</b> <small>4075 EAST MARKET STREET, YORK, PA 17402 USA</small>	
<small>MATERIAL NUMBER N/A DESCRIPTION N/A SIZE N/A DIMENSIONS ARE IN BRACKETS UNLESS OTHERWISE INDICATED LINEAR X.XX +/- .01 / - .020 ANGULAR .XX +/- .5°</small>		<b>ENGINE ALTERNATOR ASSEMBLY TIER 4</b>	<b>360-18892-00</b>
<small>DATE</small> AUV 20220429	<small>NAME</small> BES	<small>SCALE</small> N/A	<small>REV</small> D
<small>APPROVED</small> BES	<small>DRAWN</small> AUV	<small>SHEET # OF 7</small> N/A	<small>SHEET SIZE A2</small> D

- NOTES:
1. USE ITEMS RETAINED FROM DISASSEMBLY FROM SHEET 5
  2. DO NOT USE POWER TOOLS FOR THE FUEL LINE ASSEMBLY
  3. SECURE FUEL LINES WITH PROVIDED HARDWARE

UNCONTROLLED IF PRINTED

360-18892-00




12 11 10 9 8 7 6 5 4 3 2 1

DRAWING NO.  
360-18892-00


DO NOT SCALE

PASS THE OIL DRAIN HOSE THROUGH THE BRACKET AND SCREW THE DRAIN PLUG OVER THE BRACKET TO SECURE HOSE IN PLACE



DETAIL 0

OIL DRAIN HOSE MOUNTING ASSEMBLY



<b>KLINGE</b> <small>EST. 1936</small>		<b>KLINGE CORPORATION</b> 4075 EAST MARKET STREET, YORK, PA 17402 USA	
ALL PROPRIETARY INFORMATION IS THE PROPERTY OF KLINGE CORPORATION. NO PARTS OR INFORMATION ARE TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF KLINGE CORPORATION.		TITLE <b>ENGINE ALTERNATOR ASSEMBLY TIER 4</b>	CATEGORY 0K0L1
MATERIAL NUMBER N/A SPEC. N/A SIZE N/A DIMENSIONS ARE IN INCHES! UNLESS OTHERWISE INDICATED LINEAR X.XX +/- .01 +/- .020 ANGULAR XX° +/- .5°	NAME AUV	DATE 20220429	DRAWN BES
PART OR DISCLOSE MATERIAL POINT TO OTHERS WITHOUT PERMISSION BY KLINGE CORP.	APPROVED BES	SCALE N/A	REV D
DRAWING NO. <b>360-18892-00</b>		SHEET SIZE A2	

UNCONTROLLED IF PRINTED


360-18892-00

REV	DATE	DESCRIPTION	CHANGE NO	DRAWN	APPROVED
A	20221102	CHANGE ITEM 17 FROM (K21-16685-06) TO (K21-18510-06). ADD ITEM 31 (K28-10995-010). ADD NOTES ON THE PARTS THAT COME WITH ENGINE.	22-255	LAH	BES
B	20221114	ADD ITEM 32 AND CHANGE SIZE OF HARD FOR BAP SENSOR. CHANGED VIEWS OF MODELS. CHANGES IN NOTES.	22-260	LAH	BES
C	20221228	BALLOON 17 WAS 22 SECTION B-B SHEET 2. ADD ITEM #33 SHEET 2. ROTATED RELAY SOCKET 180° SHEET 2.	22-321	DBG	BES
D	20240417	ITEM #17 QTY WAS 7. ADD ITEM #34, ITEM #34 REPLACES ITEM #17 SECTION B-B SHEET 2. TITLE WAS BOX CONTROL WHITE	24-054	DBG	BES



DO NOT SCALE

DRAWING NO.  
360-18922-00



34	K21-15797-06	WASHER LOCK EXT INT SS 1/4"			1
33	360-18949-00	CABLE BATTERY CHARGER DISCONNECT WITH PLUG			1
32	K21-50421-05	WASHER, LOCK, SPRING, STAINLESS STEEL, M5 X 9.2 X 1.2			2
31	K28-10995-010	RING Ø EPDM, 25 ID X .375 OD X .06 W			1
30	360-18947-00	WIRING CONTROL			1
29	360-18941-00	HARNES CONTROL			1
28	K21-16583-06	NUT LOCK SS M6 X 1 NYLON INSERT			2
27	K21-50103-06	NUT HEX M6 THIN 18-8 SS			1
26	K21-50274-18	SCREW HEX SS M6 X 1 X 18			2
25	K21-50421-06	WASHER, LOCK, SPRING, STAINLESS STEEL, M6 X 12.2 X 1.5			5
24	K21-50401-05	WASHER, FLAT, STAINLESS STEEL, M5 X 10 X 1			2
23	K21-16400-06	SCR PAN SS M5X0.8X25MM FULLY THREADED 18-8			2
22	360-18935-00	HARNES ENGINE NMG TIER 4			1
21	K21-50224-25	SCREW, HEX, STAINLESS STEEL, FULL THREAD, M6 X 1.00 X 25			4
20	360-18921-01	BOX CONTROL ENCLOSURE ASSY PAINTED NMG TIER 4			1
19	K21-18425-04	WASH FLAT SS BONDED NEOP 1/4" Ø 275 ID .625 OD			2
18	K21-16547-06	WASHER, FLAT, STAINLESS STEEL, M6 X 18 X 16			7
17	K21-18510-06	WASHER INSULATED PVC M6			6
16	K21-18420-16	SCREW FLAT HEAD PHILLIPS SS M6-1 X 16			4
15	060-18933-01	MOUNT BRACKET RIGHT ECM PAINTED			1
14	060-18932-01	MOUNT BRACKET LEFT ECM PAINTED			1
13	K26-25310-13	POWERVIEW GENERATOR DISPLAY - 4LEZTAGY			1
12	K35-06744-00	LABEL RPM			1
11	K35-06745-00	LABEL START/ON/OFF			1
10	K35-06746-00	LABEL PREHEAT			1
9	360-18958-00	LED RED W/ FERRULE			1
8	K24-22416-00	SWITCH SPST 12V 20A / OFF SCREW TERMINAL			1
7	K24-17239-00	BOOT TOGGLE SWITCH			2
6	K24-22556-00	SWITCH TOGGLE 3 POS OFF-ON-MDM			1
5	K25-26147-01	RING SEAL PLASTIC 1/2			1
4	K25-26340-02	NUT LOCK PLASTIC 1/2			1
3	K25-26129-03	CONNECTOR STRAIGHT PLASTIC SHORT 1/2			1
2	XB-993011-20	RUBBER NEOPRENE 1/4" X 2 X 12" DUROMETER 70			1
1	360-18948-00	DOOR ASSEMBLY CONTROL BOX NMG TIER 4			1
ITEM NO	PART NO	DESCRIPTION			QTY

**KLINGE**

4075 EAST MARKET STREET, YORK, PA 17402 USA

NAME: BOX CONTROL ASSEMBLY

DATE: 20220720

AUV: 20220720

DRAWN: BES

APPROVED: BES

20220928

REV: D

SCALE: N/A

SHEET SIZE: A2

SHEET 2 OF 2

MATERIAL NUMBER N/A

SUBJECT MATTER: BOX CONTROL ASSEMBLY

HEREOF ARE: DRAWING

NO PERMISSION IS GRANTED TO REPRODUCE THIS DRAWING IN WHOLE OR IN PART WITHOUT THE WRITTEN PERMISSION OF KLINGE CORP.

OTHER DIMENSIONS (IF ANY) INDICATED IN THIS DRAWING SHALL TAKE PRECEDENCE OVER DIMENSIONS SHOWN HEREIN.

UNLESS OTHERWISE INDICATED, DIMENSIONS ARE IN INCHES.

ANGULAR DIMENSIONS ARE SHOWN AS X.X ± .01


OTHER DIMENSIONS ARE SHOWN AS X.X ± .01

BY KLINGE CORP.

NOTES:  
 1. USE ANTI-SEIZE KLINGE P/N K13-02069-00 ON ALL STAINLESS STEEL FASTENERS.  
 2. ITEM 29 AND 30 NOT SHOWN IN DRAWING.



UNCONTROLLED IF PRINTED

360-18922-00



1	2	3	4	5	6	7	8	9	10	11	12
DRAWING NO. 360-18951-00											
REV	DATE	DESCRIPTION							CHANGE NO		DRAWN APPROVED
A	20221219	MOVED JUMPERS TO UPPER SIDE OF TERMINAL BLOCK, ADDED ITEM #16							22-310	DBG	BES
B	20230329	CHANGED ALT. BREAKER BOX BACK TO JUNCTION BOX AND MOVE BREAKER BOX. CHANGED LABELS AND LOCATIONS.							23-066	LAH	BES
C	20240212	ADDED ITEM #5							24-017	DBG	BES

DO NOT SCALE



NOTE: THE ROUTING OF THE POWER CABLE HAS CHANGED. IT WILL BE COMING DOWN THROUGH TOP PANEL TO THE ALT. WHEN MAINTAINING OR REPAIRING DISCONNECT FROM ALTERNATOR FOR EASIER ACCESS THAN FROM INSIDE THE BREAKER BOX.

5	K21-16694-00	SCREW HEX HEAD GROUNDING #10-32 X 1/2"	1
4	K35-06752-00	LABEL DANGER HIGH VOLT TAGE 2.26 x 1.97	1
3	K25-26761-26	CONNR STR PLST M25 (12.3-18.0mm)	1
2	K35-06539-00	LABEL GROUND SYMBOL FMV	1
1	K24-22540-03	ALTERNATOR RFL 4-30 JUNCTION BOX RIGHT	1
ITEM NO	PART NO	DESCRIPTION	QTY

ALL PROPRIETARY INFORMATION IS HEREBY PROTECTED BY PATENT RIGHTS. NO PERMISSION IS GRANTED TO REPRODUCE THIS DRAWING IN WHOLE OR IN PART, OR TO DISCLOSE THE INFORMATION TO OTHERS WITHOUT THE WRITTEN PERMISSION OF KLINGE CORP.

MATERIAL NUMBER N/A  
 FINISH N/A  
 SIZE N/A  
 DIMENSIONS (SEE DIMENSIONS) TOLERANCES (UNLESS OTHERWISE INDICATED)  
 LINEAR X.X ± .001 (X = 1, 2, 3, 4)  
 ANGULAR X.X ± .5° (X = 1, 2, 3, 4)  
 HOLE X.X ± .001 (X = 1, 2, 3, 4)

**KLINGE**  
 KLINGE CORPORATION  
 4075 EAST MARKET STREET, YORK, PA 17402 USA

REV: C  
 DRAWN: LH  
 DATE: 20230302  
 LABEL/DRAWN: 0K0L1  
 SCALE: N/A  
 SHEET 1 OF 1



ALTERNATOR RFL-30 MODIFIED  
 DRAWING NO. 360-18951-00  
 SHEET SIZE: A2

NOTES:  
 1. USE ANTI-SEIZE KLINGE P/N K13-02069-00 ON ALL STAINLESS STEEL FASTENERS

UNCONTROLLED IF PRINTED

360-18951-00

1	2	3	4	5	6	7	8	9	10	11	12
DRAWING NO. 360-18275-10											
DO NOT SCALE											
REV DATE DESCRIPTION CHANGE NO DRAWN APPROVED											




36	K35-06462-00	LABEL BATTERY CHARGER RESET										1
35	K35-06678-01	LABEL HORN SILENCING										1
34	K24-17239-00	BOOT TGL SW										1
33	K24-18164-00	BOOT CKT BKR 3/8-27 THD CLEAR										1
32	K21-16547-05	WASH FLAT SS M5.3 X 15 X 12 LARGE OD										2
31	K21-16566-19	RIVET 3/16 (0.0-0.125) CLOSED END SS										4
30	K21-16583-06	NUT LOCK SS M6 X 1 NYLON INSERT										9
29	K21-18510-06	WASHER INSULATED PVC M6										21
28	K21-50224-30	SCREW HEX SS M6 X 1 X 30										5
27	K21-15797-06	WASHER LOCK EXT INT SS 1/4"										1
26	K21-50103-06	NUT HEX M6 THIN 18-8 SS										1
25	K21-50401-06	WASHER, FLAT, STAINLESS STEEL, M6, 6.4 X 12 X 1.6										2
24	360-18285-00	GSM ENA/KOON LOCATE 6 MODIFIED										1
23	K25-26340-02	NUT LK CONDUIT BLK NYL 1/2 NP"										5
22	K25-26129-03	CONN'R STRAIGHT PLASTIC SHORT 1/2" (170-450)										4
21	K25-26147-01	SEAL RING PLASTIC 1/2"										5
20	K21-16547-06	WASH FLAT SS M6 LARGE OD 18MM										28
19	K21-50421-06	WASHER LK SPG SS M6 18-8										6
18	K21-50224-25	SCREW HEX SS M6 X 1 X 25										6
17	360-18263-01	HORN ASSEMBLY ALARM BOX										1
16	K25-26147-02	SEAL RING PLASTIC 3/4"										3
15	K25-26340-03	NUT LK CONDUIT 3/4										3
14	K25-26129-05	CONN'R STRAIGHT PLASTIC SHORT 3/4" (450-709)										3
13	060-13055-07	RAIL MOUNTING DIN #3 X 3" LG										1
12	K24-22527-02	BARRIER INTRINSIC SAFE ZENER 6VDC AT 10uA DIN RAIL										1
11	360-15580-01	BATTERY CHARGER MODIFIED 24 VAC 12 VDC 3 AMP										1
10	K25-26941-00	3 POSITION ROTARY CAM SWITCH WITH PANEL MOUNT										1
9	K25-26947-00	SW PB INO GREEN ILL 12VDC										1
8	K24-21355-00	SWITCH TOGGLE SPDT #6 SCR										1
7	K24-22330-00	CIRCUIT BREAKER 4 AMP 250 VAC 1 POLE										1
6	K25-26838-00	LAMP ALARM LED										1
5	K28-11107-00	GROUPEM ELEC ALARM LIGHT 2.312 MOUNTING HOLE										1
4	360-18284-10	WIRING BOX ACCESSORIES POWER ALARM & GSM										1
3	360-18280-10	PANEL ACCESSORIES POWER ALARM & GSM COMPLETE										1
2	360-18280-10	COVER ACCESSORIES POWER ALARM & GSM COMPLETE										1
1	360-18276-11	BOX ACCESSORIES POWER ALARM & GSM WHITE										1

		<b>KLINGE CORPORATION</b> 4075 EAST MARKET STREET, YORK, PA 17402 USA	
<b>BOX ACCESSORIES POWER ALARM &amp; GSM COMPLETE</b>		TITLE	
DRAWING NO <b>0K011</b>	NAME DATE NWB 20241122	CAGE/DCCH <b>0K011</b>	DRAWING NO <b>360-18275-10</b>
APPROVED BES	REV 1	SCALE N/A	SHEET SIZE A2

ITEM NO	PART NO	DESCRIPTION	QTY	MATERIAL
48	K35-06538-00	LABEL GROUND SYMBOL FNV	1	
47	K25-26266-02	SPRING RELAY HOLD DOWN 2 POLE	1	
46	K25-26265-02	SOCKET RELAY DPDT 1/8 DIN MTG	1	
45	K24-22264-01	RELAY 12 VDC COIL MINI DPDT 3A	1	
44	K24-22533-00	TIMER MULTI FUNCT 0 IS TO 24HRS 12-24.0 AC/DC	1	
43	060-13055-31	RAIL MOUNTING DIN #3 X 1.75" LG	1	
42	K25-26129-07	CONN'R STRAIGHT PLASTIC SHORT 1/2 (230-546)	1	
41	K21-50421-04	WASHER LOCK SPG SS 4MM	4	
40	K21-50401-04	WASH FLAT 4MM	4	
39	K21-50103-04	NUT HEX M4 THIN 18-8 SS	4	
38	K21-16647-18	SCR FLAT SOC SS M4 X 0.7 X 18 MM	4	
37	360-18262-31	HARNES LAMP PLUG	1	

NOTES:  
 1. USE ANTI-SEIZE KLINGE P/N K13-02069-00 ON ALL STAINLESS STEEL FASTENERS.  
 2. ITEM #4 NOT SHOWN, SEE DRAWING 360-18284-10.

UNCONTROLLED IF PRINTED



	<b>KLINGE CORPORATION</b> 4075 EAST MARKET STREET, YORK, PA 17402, USA	<b>BOX ACCESSORIES POWER ALARM &amp; GSM COMPLETE</b>	TITLE 0K0L1	CASE/FIGURE N/A	DRAWING NO. 360-18275-10	REV -
	NAME NWB	DATE 2024-11-22	DRAWN BES	APPROVED N/A	SCALE N/A	SHEET SIZE A2

ALL PROPRIETARY RIGHTS IN THE SUBJECT MATTER ARE RESERVED AND NO PERMISSION IS GRANTED TO REPRODUCE OR IN ANY MANNER TO DISSEMINATE THIS INFORMATION WITHOUT THE WRITTEN RELEASE BY KLINGE CORP.

MATERIAL NUMBER DESCR SIZE  
 N/A N/A  
 DIMENSIONS ARE IN (INCHES) TOLERANCES UNLESS OTHERWISE INDICATED  
 IN WHOLE OR IN FRACTIONS USE THE FOLLOWING:  
 X = +.010 -0.010 OR +/- .040  
 XX = +/- .051 +/- .020  
 XXX = +/- .051  
 XXXX = +/- .051

UNCONTROLLED IF PRINTED